Original	Rechange	Original	Rechange
Input	AV / Input / RDS	Ok	OK
XStudioPro	TV/Radio /	Down	Down
Power	Power	Red	Red / Netflix / Search
Multimedia	Display / Media	Green	Green / APP / Repeat
Stop	Stop / Hold	Yellow	Yellow / YouTube / Repeat
Play	Play / Slow	Blue	Blue / Prime Video / Random
Pause	Pause / Step / Freeze	Vol +	Vol +
Rec	Rec / Rec Mode	PR+	CH+ / Page+
I<<	I<< / Preset-	Vol -	Vol -
<<	<< / Tune-	Mute	Mute / Dimmer
>>	>> / Tune+	Text	Text / Goto
>>I	>>I / Preset+	PR-	CH- / Page-
Menu	Menu / Home	1	1
Exit	Exit / Cancel / Clear	2	2
Left	Left	3	3
Up	Up	4	4
Right	Right	5	5

Original		Rechange	
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	LIST SMART	Smart / List
0	0	HDMI - SAT 0	0
Q.VIEW	Q. View	TOP MENU D.MENU	D. Menu / Top
SIZE	Size	SIZE ZOOM	Zoom / Size
POSITION	Position	EQ SUBTITLE	Subtitle / EQ
TIME	Time	SHIFT + TIMER SLEEP	Shift + Sleep / Timer
INDEX	Index	ANGLE INFO	Info / Angle
HOLD	Hold	SHIFT + HOLD ■	Shift + Stop /
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
REVEAL	Reveal	TITLE SOUND	Sound / Title
FAV	Fav	PC FAV MARKER	Fav / Marker / PC
I/II	I/II	LANG I/II AUDIO	Audio / Lang I/II
PIP	PIP	FORMAT PICTURE	Picture / Format

Original		Rechange	
ARC	ARC	OPT-TOOLS SETUP	Setup / OPT /

Original		Rechange	
POWER	Power	POWER	Power
	Stop	HOLD	Stop / Hold
	Play	SLOW	Play / Slow
	Pause	STEP-FREEZE	Pause / Step / Freeze
	I<<	PRESET-	I<< / Preset-
	<<	TUNE-	<< / Tune-
MARK	>>	TUNE+	>> / Tune+
LIVE TV	>>I	PRESET+	>>I / Preset+
MENU	Menu	HOME MENU	Menu / Home
	Left		Left
	Up		Up
	Right		Right
OK	OK	OK	OK
	Down		Down
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3

Original		Rechange	
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0

Original		Rechange		Original		Rechange	
	Input		AV / Input / RDS	8	8		8
	Power		Power	9	9		9
	Stop		Stop / Hold	0	0		0
	Play		Play / Slow				
	Pause		Pause / Step / Freeze				
	Rec		Rec / Rec Mode				
	<<		<< / Tune-				
	>>		>> / Tune+				
	PR+		CH+ / Page+				
	PR-		CH- / Page-				
1	1		1				
2	2		2				
3	3		3				
4	4		4				
5	5		5				
6	6		6				
7	7		7				

Original		Rechange		Original		Rechange	
POWER	Power		Power				
VOL	Vol +	VOL	Vol +				
VOL	Vol -	VOL	Vol -				
MUTE	Mute	DIMMER MUTE	Mute / Dimmer				