Original		Rechange	
	Power		Power
	Display	DISPLAY INFO	Info
DVD/BD	DVD / BD	SHIFT + 1	Shift + 1
VCR/DVR	VCR / DVR	SHIFT + 2	Shift + 2
CBL/SAT	CBL/SAT	SHIFT + 3	Shift + 3
CD	CD	SHIFT + 4	Shift + 4
AUX	AUX	SHIFT + 5	Shift + 5
TV/TAPE	TV / TAPE	SHIFT + 6	Shift + 6
TUNER	TUNER	SHIFT + 7	Shift + 7
PORT	PORT	SHIFT + 8	Shift + 8
MUTING	Muting	MUTE	Mute
CH DISC	CH/Disc/Album	CH +	Ch +
ALBUM	CH/Disc/Album	CH −	Ch -
VOL	Vol +	VOL +	Vol +
VOL	Vol -	VOL −	Vol -
	Up		Up
PLAYLIST /CATEGORY	Left		Left

Original		Rechange	
ENTER	Enter	OK	Ok
PLAYLIST /CATEGORY	Right		Right
	Down		Down
SETUP	Setup	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
AUDIO	Audio	SOUND DUAL	Dual
	I<<		I<<
	>>I		>>I
	<<		<<
	Play	PLAY MODE	Play
	>>		>>
	Pause		Pause
	Stop		Stop
MOVIE/TV SEARCH	Movie	A	Red
MUSIC REPEAT	Music/Repeat	B	Green
GAME RANDOM	Game/Random	C	Yellow
STEREO PLAY MODE	Stereo/Play Mode	D	Blue

Original		Rechange		Original	Rechange
1	1	1	1		
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0 11	0/ 11	0	0		
+10 D.TUN DIMMER	+10/ - - / - - - 10/ Di mer / D. Tun	-/-- GUIDE	Gui de		
CLR SLEEP 12	CLR/ Sl eep/ 12	FAV PRE-CH	Pre Ch		

Original		Rechange	
	Power BD/DVD		Power
	Menu/Prev CH		Menu
	Top Menu/Guide BD/DVD		Options
	Setup BD/DVD		Smart
	Return BD/DVD		Back
	Audio BD/DVD		Media
	Enter BD/DVD		Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
	Right BD/DVD		Right
	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
	Play BD/DVD		Play
	Pause/Play rev. BD/DVD		Pause

Original		Rechange	
	Stop BD/DVD		Stop
	Movie Tv/Search BD/DVD		Red
	Music/Repeat		Green
	Game/Random		Yellow
	Stereo/Play Mode BD/DVD		Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
+10	+10/--/--10/D.Tu Dimmer BD/DVD	GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

Original	Rechange	Original	Rechange
CBL/SAT	REPEAT TEXT Text	Stop CBL/SAT	SHIFT + ■ Shift + Stop
Muting Receiver	MUTE Mute	<< CBL/SAT	SHIFT + CH − Shift + Ch -
Vol + Receiver	+ VOL Vol +	>> CBL/SAT	SHIFT + + CH Shift + Ch +
Vol - Receiver	VOL − Vol -	Play CBL/SAT	ECO 3D 3D
Power CBL/SAT	SHIFT + ⏻ Shift + Power	Movie Tv/Search CBL/SAT	SOUND DUAL Dual
CH Disc/Album+ CBL/SAT	+ CH Ch +	Music/Repeat CBL/SAT	AD SUBT Subt
CH Disc/Album- CBL/SAT	CH − Ch -	Game/Random	TIMER AV AV
Menu/Prev CH CBL/SAT	SHIFT + TOP MENU MENU Shift + Menu	Stereo/Play Mode CBL/SAT	PICTURE FORMAT Format
Top Menu/Guide CBL/SAT	SHIFT + SETTINGS OPT Shift + Options	1 CBL/SAT	SHIFT + 1 Shift + 1
Return CBL/SAT	SHIFT + RETURN BACK Shift + Back	2 CBL/SAT	SHIFT + 2 Shift + 2
Setup CBL/SAT	SHIFT + HOME SMART Shift + Smart	3 CBL/SAT	SHIFT + 3 Shift + 3
Up CBL/SAT	SHIFT + ▲ Shift + Up	4 CBL/SAT	SHIFT + 4 Shift + 4
Enter CBL/SAT	SHIFT + OK Shift + Ok	5 CBL/SAT	SHIFT + 5 Shift + 5
Down CBL/SAT	SHIFT + ▼ Shift + Down	6 CBL/SAT	SHIFT + 6 Shift + 6
Right CBL/SAT	SHIFT + ▶ Shift + Right	7 CBL/SAT	SHIFT + 7 Shift + 7
Left CBL/SAT	SHIFT + ◀ Shift + Left	8 CBL/SAT	SHIFT + 8 Shift + 8
Pause/Play rev. CBL/SAT	SHIFT + ⏸ Shift + Pause	9 CBL/SAT	SHIFT + 9 Shift + 9

Original		Rechange		Original	Rechange
0 / 11	CBL / SAT	SHIFT + 0	Shift + 0		
DVD/BD	DVD / BD	SEARCH TV/R	TV / R		

Original		Rechange	
	Power CD		Power
	CH/Disc+ CD		Ch +
	CH/Disc- CD		Ch -
	Return CD		Back
	Setup CD		Smart
	Audio CD		Media
	Up CD		Up
	Down CD		Down
	Right CD		Right
	Left CD		Left
	Enter CD		Ok
	I<< CD		I<<
	>>I CD		>>I
	<< CD		<<
	>> CD		>>
	Play CD		Play
	Pause CD		Pause

Original		Rechange	
	Stop CD		Stop
	Movie Tv/Search		Red
	Music/Repeat		Green
	Game/Random		Yellow
	Stereo/Play Mode		Blue
1	1 CD	1	1
2	2 CD	2	2
3	3 CD	3	3
4	4 CD	4	4
5	5 CD	5	5
6	6 CD	6	6
7	7 CD	7	7
8	8 CD	8	8
9	9 CD	9	9
0	0/11 CD	0	0
+10	+10/--/--10/D.Tu Dimmer CD	GUIDE	Guide
CLR SLEEP	CLR/Sleep/12	PRE-CH	Pre Ch

Original		Rechange		Original		Rechange
MUTING	Muting Receiver	MUTE	Mute			
VOL	Vol + Receiver	+ VOL	Vol +			
VOL	Vol - Receiver	VOL −	Vol -			
CD	CD	SEARCH TV/R	TV/R			

Original		Rechange	
	Power Receiver Zone 2		Power
	Muting Receiver		Mute
	Vol + Zone 2		Vol +
	Vol - Zone 2		Vol -
	CH Disc/Album+ Zone 2		Ch +
	CH Disc/Album- Zone 2		Ch -
	Up Zone 2		Up
	Enter Zone 2		Ok
	Down Zone 2		Down
	Right Zone 2		Right
	Left Zone 2		Left
	Return Zone 2		Back
	Setup Zone 2		Smart
	Audio Zone 2		Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
	Play Zone 2		Play

Original		Rechange	
	>> Zone 2		>>
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
	Movie Tv/Search Zone 2		Red
	Music/Repeat		Green
	Game/Random		Yellow
	Stereo/Play Mode Zone 2		Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9

Original		Rechange		Original		Rechange	
11 0	0/ 11 Zone 2	0	0				
+10 D.TUN DIMMER	+10/ - - / - - 10/ D. Tu Di mmer Zone 2	-/-- GUIDE	Gui de				
12 CLR SLEEP	CLR/ Sl eep/ 12	FAV PRE-CH	Pr e Ch				