| Original | | Rechange | |
|---|---|---|---|
| POWER | Power | POWER | Power |
| SOURCE | Source | RDS AV INPUT | AV / Input / RDS |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD - STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX - HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| -/-- | -/-- | -/-- GUIDE EPG | Guide / EPG / -/-- |
| 0 | 0 | HDMI - SAT 0 | 0 |
| PRE-CH | PRE-CH | RETURN BACK | Back / Return |
| TV | TV | MEDIA DISPLAY | Display / Media |
| CH MGR | CH. MGR | LIST SMART | Smart / List |
| SLEEP | Sleep | TIMER SLEEP | Sleep / Timer |

| Original | | Rechange | |
|---|---|---|---|
| PC | PC | PC FAV MARKER | Fav / Marker / PC |
| VOL + | Vol + | + VOL | Vol + |
| P+ | P+ | + CH PAGE | CH+ / Page+ |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| VOL - | Vol - | VOL - | Vol - |
| P- | P- | CH PAGE - | CH- / Page- |
| MENU | Menu | HOME MENU | Menu / Home |
| EXIT | Exit | CLEAR EXIT CANCEL | Exit / Cancel / Clear |
| Up | Up | Up | Up |
| Left | Left | Left | Left |
| ENTER | Enter | OK | OK |
| Right | Right | Right | Right |
| Down | Down | Down | Down |
| PIP | [≡+] / PIP | SLOW | Play / Slow |
| INFO | [≡?] / Info | ANGLE INFO | Info / Angle |
| TTX/MIX | TTX/MIX | GOTO TEXT | Text / Goto |
| P.MODE | Red / P.Mode | NETFLIX SEARCH | Red / Netflix / Search |

| Original | | Rechange | | Original | Rechange |
|---|---|---|---|---|---|
| P.MODE | Red / P. Mode | FORMAT PICTURE | Picture / Format | | |
| S.MODE | Green / S. Mode | APP REPEAT | Green / APP / Repeat | | |
| S.MODE | Green / S. Mode | TITLE SOUND | Sound / Title | | |
| STILL | Yellow / Still | YouTube REPEAT A-B | Yellow / YouTube / Repeat | | |
| STILL | Yellow / Still | STEP-FREEZE | Pause / Step / Freeze | | |
| P.SIZE | Blue / P. Size | Prime Video RANDOM | Blue / Prime Video / Random | | |
| SOURCE | [≡♦] / PIP Sourc | HOLD | Stop / Hold | | |
| SWAP | [≡◊] / PIP Swap | TUNE+ | >> / Tune+ | | |
| SIZE | Size | SIZE ZOOM | Zoom / Size | | |
| P | PIP P+ | PRESET+ | >>I / Preset+ | | |
| DUAL I-II | I-II / Dual | LANG I/II AUDIO | Audio / Lang I/II | | |
| SRS | (o) / SRS | SURROUND | Eject / Surround | | |
| POSITION | PIP Position | TUNE- | << / Tune- | | |
| P | PIP P- | PRESET- | I<< / Preset- | | |
| | | | | | |
| | | | | | |
| | | | | | |