Original		Replacement	
POWER	Power		Power
DVD	DVD	D	Blue
TUNER	Tuner	B	Green
USB	USB	C	Yellow
AUX	AUX	A	Red
	Open/Close	ZOOM	Eject
SLEEP	Sleep	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0

Original		Replacement	
REMAIN	Remain	HOME SMART	Smart
CANCEL	Cancel	APP MEDIA	Media
	I<<		I<<
	>>I		>>I
	<<		<<
	>>		>>
STOP	Stop		Stop
PLAY	Play	PLAY MODE	Play
PLAY	Pause		Pause
STEP	Step	SETTINGS OPT	Options
REPEAT	Repeat	REPEAT TEXT	Text
VOLUME	Vol+	+ VOL	Vol +
VOLUME	Vol-	VOL −	Vol -
MUTE	Mute	MUTE	Mute
TUNING	Tuning Up	+ CH	Ch +
TUNING	Tuning Down	CH −	Ch -
MENU	Menu	TOP MENU MENU	Menu

Original		Replacement		Original	Replacement
RETURN	Return	RETURN BACK	Back		
PRESET	Preset Up		Up		
PRESET	Preset Down		Down		
SEEK UP	Right/Seek Up		Right		
SEEK DOWN	Left/Seek Down		Left		
ENTER	Enter	OK	Ok		
AUDIO	Audio	SOUND DUAL	Dual		
SUBTITLE	Subtitle	AD SUBT	Subt		
INFO	Info	DISPLAY INFO	Info		
EXIT	Exit	CLEAR EXIT	Exit		
P.SOUND	P.Sound	SHIFT + SOUND DUAL	Shift + Dual		
EQ	EQ	ECO 3D	3D		
MO/ST ZOOM	Zoom/Mo/ST	SHIFT + ZOOM	Shift + Eject		
AUTO SCAN ANGLE	Angle/Autoscan	-/-- GUIDE	Guide		