Mandis shop

RM-D597

Original		Replacement	
A.SPACE/ A.CUE	A.Space/A.Cue	HOME SMART	Smart
MUSIC SCAN	Music Scan	APP MEDIA	Media
CONTINUE	Play Mode	SOUND DUAL	Dual
PLAY MODE SHUFFLE	Play Mode Shuffle	AD SUBT	Subt
PROGRAM	Play Mode	SETTINGS OPT	Options
CLEAR	Clear	CLEAR EXIT	Exit
FADER	Fader	MUTE	Mute
REPEAT	Repeat	REPEAT TEXT	Text
TIME	Time	TIMER AV	AV
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8

Original		Replacement	
9	9	9	9
10	10	0	0
>10	>10	GUIDE	Guide
+ LINE OUT LEVEL	Line Out Level+	+ VOL	Vol +
LINE OUT LEVEL –	Line Out Level-	VOL –	Vol -
▶	Play	PLAY MODE ▶	Play
❚❚	Pause	❚❚	Pause
■	Stop	■	Stop
AMS ▶▶❚	>>I	▶▶❚	>>I
AMS ❚◀◀	I<<	❚◀◀	I<<
▶▶	>>	▶▶	>>
◀◀	<<	◀◀	<<

https://all-remote-controls.nl/en/Sony/1062465-30870-replacement-remote-control-for-Sony-RM-D597.html