Original		Replacement	
	POWER		Power
	MUTE	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
-/--	-/--	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
0	0	HDMI - SAT 0	0
	RECALL	RETURN BACK	Back / Return
	RED	NETFLIX SEARCH	Red / Netflix / Search
	GREEN	APP REPEAT	Green / APP / Repeat
	YELLOW	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Original		Replacement	
	BLUE	Prime Video RANDOM	Blue / Prime Video / Random
MENU	MENU	HOME MENU	Menu / Home
VOL	VOL+	+ VOL	Vol+
CH	CH+	+ CH PAGE	CH+ / Page+
INFO	INFO	ANGLE INFO	Info / Angle
VOL	VOL-	VOL −	Vol-
CH	CH-	CH PAGE −	CH- / Page-
	<<	TUNE- <<	<< / Tune-
	>>	TUNE+ >>	>> / Tune+
	PLAY/PAUSE	SLOW ▶	Play / Slow
	PLAY/PAUSE	STEP - FREEZE ❚❚	Pause / Step / Freeze
	STOP	HOLD ■	Stop / Hold
	UP	▲	Up
	LEFT	◀	Left
OK	OK	OK	OK
	RIGHT	▶	Right
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--

Original	Replacement	Original	Replacement
DOWN	Down		
EXIT	Exit / Cancel / Clear		
FORMAT	Picture / Format		
AUDIO	Audio / Lang I/II		
TEXT	Text / Goto		
PIP	Display / Media		
Timer	SHIFT + TIMER SLEEP: Shift + Sleep / Timer		
zzZ	TIMER SLEEP: Sleep / Timer		