Mandis shop

# Denon RC-235

| Original | | Replacement | |
|---|---|---|---|
| RANDOM | Random | HOME SMART | Smart |
| DISPLAY | Display | DISPLAY INFO | Info |
| PROG/DIRECT | Prog/Direct | PROG SLEEP | Sleep |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| +10 | +10 | -/-- GUIDE | Guide |
| CALL | Call | FAV PRE-CH | Pre Ch |
| VOLUME | Vol+ | + VOL | Vol + |
| VOLUME | Vol- | VOL – | Vol - |

| Original | | Replacement | |
|---|---|---|---|
| PLAY | Play | PLAY MODE ▶ | Play |
| PAUSE | Pause | ❚❚ | Pause |
| STOP | Stop | ■ | Stop |
| ⏮ | I<< | ⏮ | I<< |
| ⏭ | >>I | ⏭ | >>I |
| << | << | << | << |
| >> | >> | >> | >> |
| PITCH – | Pitch- | CH – | Ch - |
| PITCH + | Pitch+ | + CH | Ch + |

https://all-remote-controls.nl/en/Denon/1062722-91682-replacement-remote-control-for-Denon-RC-235.html