Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Swap	Smart / List	Subtitle	Subtitle / EQ
Text	Text / Goto	i	Info / Angle
Media	Display / Media	V-Format	Picture / Format
Power	Power	Vol +	Vol +
Mute	Mute / Dimmer	Page+	Shift + CH+ /
1	1	P+	CH+ / Page+
2	2	Vol -	Vol -
3	3	Page-	Shift + CH- /
4	4	P-	CH- / Page-
5	5	Audio	Audio / Lang I/II
6	6	AD	Shift + Audio / Lang I/II
7	7	Sound / TV/Radio	Sound / Title
8	8	Guide	Guide / EPG / -/--
9	9	Up	Up
0	0	Left	Left
Back	Back / Return	OK	OK
FAV	Fav / Marker / PC	Right	Right

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
MENU M	Menu	HOME MENU	Menu / Home		
	Down		Down		
EXIT X	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
	Red	NETFLIX SEARCH	Red / Netflix / Search		
	Green	APP REPEAT	Green / APP / Repeat		
	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
	Play	SLOW	Play / Slow		
	Pause	STEP-FREEZE	Pause / Step / Freeze		
	Stop	HOLD	Stop / Hold		
	Rec	REC MODE	Rec / Rec Mode		
	<<	TUNE-	<< / Tune-		
	>>	TUNE+	>> / Tune+		
	I<<	PRESET-	I<< / Preset-		
	>>I	PRESET+	>>I / Preset+		
TIMER	Timer	TIMER SLEEP	Sleep / Timer		
	Aspect	SIZE ZOOM	Zoom / Size		