Originalfernbedienung		Ersatzfernbedienung	
POWER	Power	POWER	Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
1	1	TV 1	1
ABC 2	2	DVD 2	2
DEF 3	3	CD - STB 3	3
GHI 4	4	VIDEO 4	4
JKL 5	5	TAPE 5	5
MNO 6	6	TUNER 6	6
PQRS 7	7	AUX - HDD 7	7
TUV 8	8	USB 8	8
WXYZ 9	9	BLUETOOTH 9	9
0	0	HDMI - SAT 0	0
INFO	Info	ANGLE INFO	Info / Angle
EPG	Epg	-/-- GUIDE EPG	Guide / EPG / -/--
MENU	Menu	HOME MENU	Menu / Home
CH	CH+	+ CH PAGE	CH+ / Page+
CH	Up		Up

Originalfernbedienung		Ersatzfernbedienung	
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
VOL	Left		Left
VOL	Vol -	VOL –	Vol -
OK	Ok	OK	OK
VOL	Right		Right
VOL	Vol +	+ VOL	Vol +
MEDIA	Media	MEDIA DISPLAY	Display / Media
CH	CH-	CH PAGE –	CH- / Page-
CH	Down		Down
TV/RADIO	TV/Radio	PROGRAM TV/ RADIO	TV/Radio /
SLEEP	Sleep/Red	TIMER SLEEP	Sleep / Timer
SUBTITLE	Subtitle/Green	EQ SUBTITLE	Subtitle / EQ
TELETEXT	Teletext/Yello	GOTO TEXT	Text / Goto
AUDIO	Audio/Blue	LANG I/II AUDIO	Audio / Lang I/II
	<<	TUNE-	<< / Tune-
	Play	SLOW	Play / Slow
	Pause	STEP - FREEZE	Pause / Step / Freeze

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
	>>	TUNE+	>> / Tune+		
PREV	Prev	PRESET-	I << / Preset-		
	Rec	REC MODE	Rec / Rec Mode		
FAV	FAV	PC FAV MARKER	Fav / Marker / PC		
	Stop	HOLD	Stop / Hold		