Originalfernbedienung		Ersatzfernbedienung	
RECEIVER	Power Receiver		Power
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TV CONTROL	Tv Control	SHIFT +	Shift + Power
INPUT	← Input Select	CH PAGE −	CH- / Page-
ELECT	Input Select →	+ CH PAGE	CH+ / Page+
INPUT	Input TV	RDS AV INPUT	AV / Input / RDS
BD	BD	TAPE 5	5
DVD	DVD	DVD 2	2
CD	CD	CD - STB 3	3
+ CH	CH+ Tv	SHIFT + + CH PAGE	Shift + CH+ /
TUNER	Tuner	TUNER 6	6
iPod/USB	iPod/USB	USB 8	8
SAT/CBL	SAT/CBL	HDMI - SAT 0	0
CH −	CH- Tv	SHIFT + CH PAGE −	Shift + CH- /
GAME	Game	AUX - HDD 7	7
TV	TV	TV 1	1
SIGNAL SEL	Signal Sel	FORMAT PICTURE	Picture / Format

Originalfernbedienung		Ersatzfernbedienung	
+ VOL	Vol + Tv	SHIFT + + VOL	Shift + Vol +
Acous.EQ	Acous. EQ	EQ SUBTITLE	Subtitle / EQ
S.RETRIEVER	S. Retriever	TITLE SOUND	Sound / Title
PHASE	Phase	SIZE ZOOM	Zoom / Size
VOL −	Vol - Tv	SHIFT + VOL −	Shift + Vol -
AUTO/ DIRECT	Auto / Direct	NETFLIX SEARCH	Red / Netflix / Search
STEREO	Stereo	APP REPEAT	Green / APP / Repeat
ALC/ STANDARD	ALC/ Standard	YouTube REPEAT A-B	Yellow / YouTube / Repeat
ADV SURR ECO	Eco/ ADV Surr	Prime Video RANDOM	Blue / Prime Video / Random
AUDIO PARAMETER TOP MENU	Audio	LANG I/II AUDIO	Audio / Lang I/II
TUNE	Up		Up
VOLUME +	Vol +	+ VOL	Vol +
PRESET	Left		Left
ENTER	Enter	OK	OK
PRESET	Right		Right
TUNE	Down		Down
−	Vol -	VOL −	Vol -

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
HOME MENU PTY iPod CTRL	Home Menu	HOME MENU	Menu / Home		
RETURN BAND	Return	RETURN BACK	Back / Return		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
− BASS	I <</ Bass-	PRESET-	I << / Preset-		
BASS +	>>I / Bass+	PRESET+	>>I / Preset+		
− TRE	<</ Tre-	TUNE-	<< / Tune-		
TRE +	>>/ Tre+	TUNE+	>> / Tune+		
DISP	Disp	MEDIA DISPLAY	Display / Media		
4	4	VIDEO 4	4		
SB CH 5	SB CH	ANGLE INFO	Info / Angle		
CH SELECT 6	CH Select	SHIFT + OK	Shift + OK		
MIDNIGHT 7	Midnight	TOP MENU D.MENU	D. Menu / Top		
SPEAKERS 8	Speakers	OPT-TOOLS SETUP	Setup / OPT /		
LEV+ 9	Level +	SHIFT + ▲	Shift + Up		
LEV− ENTER	Level -	SHIFT + ▼	Shift + Down		
DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer		

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung		Ersatzfernbedienung	
RECEIVER	Power Receiver		Power	SB CH 5	5	TAPE 5	5
TUNE	Tune Up	TUNE+	>> / Tune+	CH SELECT 6	6	TUNER 6	6
TOOLS MENU	Menu Tools	HOME MENU	Menu / Home	MIDNIGHT 7	7	AUX - HDD 7	7
VOLUME +	Vol +	+ VOL	Vol +	SPEAKERS 8	8	USB 8	8
PRESET	Preset-	PRESET-	I << / Preset-	LEV + 9	9	BLUETOOTH 9	9
ENTER	Enter	OK	OK	0	0	HDMI - SAT 0	0
PRESET	Preset +	PRESET+	>>I / Preset+	DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
TUNE	Tune Down	TUNE-	<< / Tune-				
−	Vol -	VOL −	Vol -				
HOME MENU PTY iPod CTRL	PTY/iPod Control	GOTO TEXT	Text / Goto				
BAND RETURN	Band	LIST SMART	Smart / List				
MUTE	Mute	DIMMER MUTE	Mute / Dimmer				
1	1	TV 1	1				
2	2	DVD 2	2				
3	3	CD - STB 3	3				
DISP	Disp	MEDIA DISPLAY	Display / Media				
4	4	VIDEO 4	4				

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Power Receiver	Power	<<	<< / Tune-
Audio	Audio / Lang I/II	>>	>> / Tune+
Up	Up	Disp	Display / Media
Vol +	Vol +	Repeat	Green / APP / Repeat
Left	Left	Random	Blue / Prime Video / Random
Enter	OK		
Right	Right		
Down	Down		
Vol -	Vol -		
PTY/iPod Control	Text / Goto		
Return	Back / Return		
Pause	Pause / Step / Freeze		
Stop	Stop / Hold		
Play	Play / Slow		
Mute	Mute / Dimmer		
I <<	I << / Preset-		
>>I	>>I / Preset+		