Mandis shop

REMCON2008

Originalfernbedienung		Ersatzfernbedienung	
PROGRAM	Program	PROGRAM TV/ RADIO	TV/Radio /
-10	-10	-/-- GUIDE EPG	Guide / EPG / -/--
+10	+10	PC FAV MARKER	Fav / Marker / PC
▶/II	Play	SLOW ▶	Play / Slow
▶/II	Pause	STEP - FREEZE II	Pause / Step / Freeze
I◀◀/◀◀	<<	TUNE- ◀◀	<< / Tune-
I◀◀/◀◀	I<<	PRESET- I◀◀	I<< / Preset-
▶▶/▶▶I	>>	TUNE+ ▶▶	>> / Tune+
▶▶/▶▶I	>>I	PRESET+ ▶▶I	>>I / Preset+
STOP	Stop	HOLD ■	Stop / Hold
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat
VOL-	Vol-	VOL −	Vol-
VOL+	Vol+	+ VOL	Vol+

Originalfernbedienung	Ersatzfernbedienung

https://all-remote-controls.nl/de/PRO-BASIC/1066622-96443-ersatzfernbedienung-fur-PRO-BASIC-REMCON2008.html