Originalfernbedienung		Ersatzfernbedienung	
TV/Rad	Tv/Rad	PROGRAM TV/RADIO	TV/Radio /
TEXT	Input/Text	GOTO TEXT	Text / Goto
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
BACK	Back	RETURN BACK	Back / Return
Opt	Red	NETFLIX SEARCH	Red / Netflix / Search
Opt	Opt.	OPT-TOOLS SETUP	Setup / OPT /
A/V+	Green	APP REPEAT	Green / APP / Repeat

Originalfernbedienung		Ersatzfernbedienung	
A/V+	A/V+	RDS AV INPUT	AV / Input / RDS
Fav	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat
Fav	FAV	PC FAV MARKER	Fav / Marker / PC
A-Z	Blue/A-Z	Prime Video RANDOM	Blue / Prime Video / Random
EPG	EPG	-/-- GUIDE EPG	Guide / EPG / -/--
INFO	Info	ANGLE INFO	Info / Angle
MENU	Menu	HOME MENU	Menu / Home
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
P-	P-	CH PAGE −	CH- / Page-
P+	P+	CH PAGE +	CH+ / Page+
PLAY	Play	SLOW	Play / Slow
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
REW	<<	TUNE-	<< / Tune-
STOP	Stop	HOLD	Stop / Hold
FF	>>	TUNE+	>> / Tune+
REC	Rec	REC MODE	Rec / Rec Mode
LIST	List	LIST SMART	Smart / List

Originalfernbedienung	Ersatzfernbedienung
SLOW I>/ Slow	MEDIA DISPLAY Display / Media
A-B A-B	SHIFT + YouTube REPEAT A-B Shift + Yellow / YouTube /
MARK Mark	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC
PIP PIP	SIZE ZOOM Zoom / Size
JUMP Jump	FORMAT PICTURE Picture / Format
MOVE Movie	SURROUND Eject / Surround
Up	Up
SWAP Swap	TOP MENU D.MENU D. Menu / Top
Down	Down
Right	Right
Left	Left
1 1 TV	SHIFT + TV 1 Shift + 1
2 2 TV	SHIFT + DVD 2 Shift + 2
3 3 TV	SHIFT + CD - STB 3 Shift + 3
4 4 TV	SHIFT + VIDEO 4 Shift + 4
5 5 TV	SHIFT + TAPE 5 Shift + 5
6 6 TV	SHIFT + TUNER 6 Shift + 6

Originalfernbedienung	Ersatzfernbedienung
7 7 TV	SHIFT + AUX - HDD 7 Shift + 7
8 8 TV	SHIFT + USB 8 Shift + 8
9 9 TV	SHIFT + BLUETOOTH 9 Shift + 9
0 0 TV	SHIFT + HDMI - SAT 0 Shift + 0
MUTE Mute TV	SHIFT + DIMMER MUTE Shift + Mute / Dimmer
TEXT Input/Text TV	SHIFT + GOTO TEXT Shift + Text /
P+ TV	SHIFT + CH PAGE + Shift + CH+ /
P- TV	SHIFT + CH PAGE − Shift + CH- /
Vol -	VOL − Vol -
Vol - TV	SHIFT + VOL − Shift + Vol -
SLEEP Sleep	TIMER SLEEP Sleep / Timer
PWR Power Tv	SHIFT + Power Shift + Power
Vol + TV	SHIFT + VOL + Shift + Vol +
PWR Power	Power
OK	OK OK
Vol +	VOL + Vol +