Originalfernbedienung		Ersatzfernbedienung	
POWER	Power	POWER	Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REW	<<	TUNE-	<< / Tune-
FF	>>	TUNE+	>> / Tune+
P Down		PRESET-	I<< / Preset-
P Up		PRESET+	>>I / Preset+
DUAL I-II	I-II / Dual	LANG I/II AUDIO	Audio / Lang I/II
SRS	(o) / SRS	EQ SUBTITLE	Subtitle / EQ
	[≡+] / PIP	FORMAT PICTURE	Picture / Format
	[≡◆] / Swap	SIZE ZOOM	Zoom / Size
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
TV	TV	PROGRAM TV/RADIO	TV/Radio /
TTX/MIX	TTX/MIX	GOTO TEXT	Text / Goto
SOURCE	Source	RDS AV INPUT	AV / Input / RDS

Originalfernbedienung		Ersatzfernbedienung	
MENU	[≡i] / Menu	HOME MENU	Menu / Home
	Up		Up
INFO	[≡?] / Info	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
EXIT	[≡x] / Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
	Vol +	VOL +	Vol +
P	P+	CH PAGE +	CH+ / Page+
	Vol -	VOL −	Vol -
DNIe	DNIe	MEDIA DISPLAY	Display / Media
	P-	CH PAGE −	CH- / Page-
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4

Originalfernbedienung		Ersatzfernbedienung		Originalfernbedienung	Ersatzfernbedienung
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--		
0	0	HDMI - SAT 0	0		
PRE-CH	[≡o] / Pre-CH	PC FAV MARKER	Fav / Marker / PC		
P.MODE	Red/-I[ ]I-/P. Mo	NETFLIX SEARCH	Red / Netflix / Search		
S.MODE	Green/-I♪I-/S. Mo e	APP REPEAT	Green / APP / Repeat		
STILL	Yellow/[▼]/Still	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
P.SIZE	Blue/[<>]/P. Size	Prime Video RANDOM	Blue / Prime Video / Random		
TIME	Time	SHIFT + TIMER SLEEP	Shift + Sleep / Timer		

Originalfernbedienung		Ersatzfernbedienung	
POWER	Power		Power
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
STOP	Stop	HOLD	Stop / Hold
REW	<<	TUNE-	<< / Tune-
FF	>>	TUNE+	>> / Tune+
TV	TV	PROGRAM TV/ RADIO	TV/ Radio /
MENU	[≡i] / Menu	HOME MENU	Menu / Home
	Up		Up
INFO	[≡?] / Info	ANGLE INFO	Info / Angle
	Left		Left
ENTER	Enter	OK	OK
	Right		Right
EXIT	[≡x] / Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
	Down		Down
	Vol +	VOL	Vol +

Originalfernbedienung		Ersatzfernbedienung	
	Vol -	VOL	Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0

Originalfernbedienung	Ersatzfernbedienung
Power	Power
Mute	Mute / Dimmer
Play	Play / Slow
Pause	Pause / Step / Freeze
Stop	Stop / Hold
<<	<< / Tune-
>>	>> / Tune+
Sleep	Sleep / Timer
TV	TV/ Radio /
Source	AV / Input / RDS
[≡i] / Menu	Menu / Home
Up	Up
[≡?] / Info	Info / Angle
Left	Left
Enter	OK
Right	Right
[≡x] / Exit	Exit / Cancel / Clear

Originalfernbedienung	Ersatzfernbedienung
Down	Down
Vol +	Vol +
P+	CH+ / Page+
Vol -	Vol -
P-	CH- / Page-
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
0	0
[≡o] / Pre-CH	Fav / Marker / PC
Power Cable	Shift + Power

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
P+ Cabl e	SHIFT + CH PAGE		
P- Cabl e	SHIFT + CH PAGE		
1 Cabl e	SHIFT + TV 1		
2 Cabl e	SHIFT + DVD 2		
3 Cabl e	SHIFT + CD - STB 3		
4 Cabl e	SHIFT + VIDEO 4		
5 Cabl e	SHIFT + TAPE 5		
6 Cabl e	SHIFT + TUNER 6		
7 Cabl e	SHIFT + AUX - HDD 7		
8 Cabl e	SHIFT + USB 8		
9 Cabl e	SHIFT + BLUETOOTH 9		
0 Cabl e	SHIFT + HDMI - SAT 0		

Originalfernbedienung		Ersatzfernbedienung	
POWER	Power		Power
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
0	0	HDMI-SAT 0	0
TV	TV	PROGRAM TV/RADIO	TV/Radio /
STOP	Stop	HOLD	Stop / Hold
PLAY/PAUSE	Play	SLOW	Play / Slow
PLAY/PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
FF	>>	TUNE+	>> / Tune+
REW	<<	TUNE-	<< / Tune-

Originalfernbedienung		Ersatzfernbedienung	
MUTE	Mute	DIMMER MUTE	Mute / Dimmer
P	P+	CH PAGE +	CH+ / Page+
	P-	CH PAGE −	CH- / Page-
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -
ENTER	Enter	OK	OK
	Up		Up
	Down		Down
	Right		Right