| Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|
| | Power | | Power |
| | Caption | EQ SUBTITLE | Subtitle / EQ |
| | AV Mode | GOTO TEXT | Text / Goto |
| | [ ]/Ratio | MEDIA DISPLAY | Display / Media |
| | Input | RDS AV INPUT | AV / Input / RDS |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| LIST | List | SHIFT + LIST SMART | Shift + Smart / List |
| 0 | 0 | HDMI-SAT 0 | 0 |
| FLASHBK | Flashbk | SIZE ZOOM | Zoom / Size |

| Originalfernbedienung | | Ersatzfernbedienung | |
|---|---|---|---|
| VOL | Vol + | VOL | Vol + |
| FAV | FAV | PC FAV MARKER | Fav / Marker / PC |
| CH | CH+ | CH PAGE | CH+ / Page+ |
| VOL | Vol - | VOL | Vol - |
| INFO | Info | ANGLE INFO | Info / Angle |
| CH | CH- | CH PAGE | CH- / Page- |
| MUTE | Mute | DIMMER MUTE | Mute / Dimmer |
| SETTINGS | Settings | OPT-TOOLS SETUP | Setup / OPT / |
| SMART | Smart | LIST SMART | Smart / List |
| MY APPS | My APPS | SHIFT + APP REPEAT | Shift + Green / APP / |
| | Up | | Up |
| | Left | | Left |
| OK | OK | OK | OK |
| | Right | | Right |
| | Down | | Down |
| BACK | Back | RETURN BACK | Back / Return |
| Q.MENU | Q. Menu | TOP MENU D.MENU | D. Menu / Top Menu |

| Originalfernbedienung | | Ersatzfernbedienung | Originalfernbedienung | Ersatzfernbedienung |
|---|---|---|---|---|
| EXIT | Exit | CLEAR EXIT CANCEL — Exit / Cancel / Clear | | |
| ● | Red | NETFLIX SEARCH — Red / Netflix / Search | | |
| ●● | Green | APP REPEAT — Green / APP / Repeat | | |
| ●● | yellow | YouTube REPEAT A-B — Yellow / YouTube / Repeat | | |
| ●● | Blue | Prime Video RANDOM — Blue / Prime Video / Random | | |
| ■ | Stop | HOLD ■ — Stop / Hold | | |
| ▶ | Play | SLOW ▶ — Play / Slow | | |
| II | Pause | STEP-FREEZE II — Pause / Step / Freeze | | |
| ◀◀ | << | TUNE- ◀◀ — << / Tune- | | |
| ▶▶ | >> | TUNE+ ▶▶ — >> / Tune+ | | |
| SIMPLINK | Simplink | FORMAT PICTURE — Picture / Format | | |
| SLEEP | Sleep | TIMER SLEEP — Sleep / Timer | | |
| VD/* | VD/* | SURROUND ⏏ — Eject / Surround | | |
| TV | TV | PROGRAM TV/RADIO — TV/Radio / | | |
| | | | | |
| | | | | |
| | | | | |