Originalfernbedienung		Ersatzfernbedienung	
DVD	Power DVD	SHIFT +	Shift + Power
TV	Power TV		Power
CH	CH + TV	SHIFT + CH	Shift + CH+ /
VOLUME	Vol + TV	VOL	Vol +
DRIVE SELECT	Select Drive	LIST SMART	Smart / List
AV	AV TV	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
CH	CH - TV	SHIFT + CH PAGE	Shift + CH- /
VOLUME	Vol - TV	VOL	Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
PAGE CH	CH / Page +	CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH	CH / Page -	CH PAGE	CH- / Page-
7	7	AUX-HDD 7	7

Originalfernbedienung		Ersatzfernbedienung	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
ShowView	ShowView	SHIFT + MEDIA DISPLAY	Shift + Display / Media
*	*	PC FAV MARKER	Fav / Marker / PC
0	0	HDMI-SAT 0	0
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
DELETE	Delete	CLEAR EXIT CANCEL	Exit / Cancel / Clear
SKIP	I<< Skip	PRESET-	I<< / Preset-
SKIP	Skip >>I	PRESET+	>>I / Preset+
SLOW/	<< Slow / Search	TUNE-	<< / Tune-
SEARCH	Slow / Search >>	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY/x1.3	Play / x1.3	SLOW	Play / Slow
i	i	ANGLE INFO	Info / Angle
PROG/CHECK	Prog / Check	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Direct Navigator	Menu / Home	Audio	Audio / Lang I/II
Up	Up	Status	Setup / OPT /
Functions	D.Menu / Top	Display	Display / Media
◁II / Left	Left	Time Slip	Sleep / Timer
Enter	OK		
Right / II▷	Right		
S / Sub Menu	Shift + Menu /		
Down	Down		
Return	Back / Return		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow / Create Chapter	Yellow / YouTube / Repeat		
Blue / Manual	Blue / Prime Video / Random		
Rec	Rec / Rec Mode		
Rec Mode	Shift + Rec / Rec Mode		
Ext Link	Eject / Surround		
Direct Tv Rec	TV/Radio / Program		