Originalfernbedienung		Ersatzfernbedienung
RECEIVER	Power Receiver	Power
DISPLAY	Display Receiver	Info
ENTER	Enter Receiver	Ok
	Up Receiver	Up
	Down Receiver	Down
PLAYLIST	Right Receiver	Right
PLAYLIST	Left Receiver	Left
RETURN	Return Receiver	Back
SETUP	Setup Receiver	Options
AUDIO HOME	Home/Audio	Smart
	Play Receiver	Play
	I<< Receiver	I<<
	>>I Receiver	>>I
	<< Receiver	<<
	>> Receiver	>>
	Pause/Play reverse Receiver	Pause
	Stop Receiver	Stop

Originalfernbedienung		Ersatzfernbedienung
1	1 Receiver	1
2	2 Receiver	2
3	3 Receiver	3
4	4 Receiver	4
5	5 Receiver	5
6	6 Receiver	6
7	7 Receiver	7
8	8 Receiver	8
9	9 Receiver	9
11 0	0/11 Receiver	0
10 +10 D.TUN DIMMER	+10/---/---10/Dimer/D.Tun Receive	GUIDE Guide
12 CLR SLEEP	CLR/Sleep/12 Receiver	FAV PRE-CH Pre Ch
SEARCH MOVIE/TV	Movie Tv/Search Receiver	A Red
REPEAT MUSIC	Music/Repeat Receiver	B Green
RANDOM GAME	Game/Random Receiver	C Yellow
MODE THX	THX/Mode	D Blue
MUTING	Muting	MUTE Mute

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
Vol + Receiver	Vol +	Setup USB	Shift + Options
Vol - Receiver	Vol -	Play USB	Shift + Play
CH/Disc/Album+ Receiver	Ch +	<< USB	Shift + <<
CH/Disc/Album- Receiver	Ch -	>> USB	Shift + >>
Menu USB	Menu	Pause USB	Shift + Pause
Top Menu USB	Shift + Menu	Stop USB	Shift + Stop
Mode USB	Format	>>I USB	Shift + >>I
Search USB	TV/R	I<< USB	Shift + I<<
Random USB	Eject	TV / CD	Shift + 8
Repeat USB	Text	TUNER	Shift + 7
Return USB	Shift + Back	PORT	Shift + 9
Right USB	Shift + Right	AUX	Shift + 6
Down USB	Shift + Down	VCR / DVR	Shift + 2
Enter USB	Shift + Ok	GAME	Shift + 4
Left USB	Shift + Left	PC	Shift + 5
Up USB	Shift + Up	CBL / SAT	Shift + 3
Display USB	Shift + Info	BD / DVD	Shift + 1

Originalfernbedienung		Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
NET	NET	SHIFT + GUIDE Shift + Guide		
USB	USB	SHIFT + 0 Shift + 0		

Originalfernbedienung		Ersatzfernbedienung	
SOURCE	Power BD/DVD		Power
PREV CH/MENU VIDEO	Menu/Prev CH	TOP MENU MENU	Menu
GUIDE/TOP MENU	Top Menu/Guide BD/DVD	SETTINGS OPT	Options
SETUP	Setup BD/DVD	HOME SMART	Smart
RETURN	Return BD/DVD	RETURN BACK	Back
AUDIO HOME	Audio/Home	APP MEDIA	Media
ENTER	Enter BD/DVD	OK	Ok
	Up BD/DVD		Up
	Down BD/DVD		Down
PLAYLIST	Right BD/DVD		Right
PLAYLIST	Left BD/DVD		Left
	I<< BD/DVD		I<<
	>>I BD/DVD		>>I
	<< BD/DVD		<<
	>> BD/DVD		>>
	Play BD/DVD	PLAY MODE	Play
	Pause/Play rev. BD/DVD		Pause

Originalfernbedienung		Ersatzfernbedienung	
	Stop BD/DVD		Stop
SEARCH MOVIE/TV	Movie Tv/Search BD/DVD	A	Red
REPEAT MUSIC	Music/Repeat	B	Green
RANDOM GAME	Game/Random	C	Yellow
MODE THX	Stereo/Play Mode BD/DVD	D	Blue
1	1 BD/DVD	1	1
2	2 BD/DVD	2	2
3	3 BD/DVD	3	3
4	4 BD/DVD	4	4
5	5 BD/DVD	5	5
6	6 BD/DVD	6	6
7	7 BD/DVD	7	7
8	8 BD/DVD	8	8
9	9 BD/DVD	9	9
11 0	0/11 BD/DVD	0	0
+10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer BD/DVD	GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
CBL/SAT	Text	Stop CBL/SAT	Shift + Stop
Muting Receiver	Mute	<< CBL/SAT	Shift + Ch -
Vol + Receiver	Vol +	>> CBL/SAT	Shift + Ch +
Vol - Receiver	Vol -	Play CBL/SAT	3D
Power CBL/SAT	Shift + Power	Movie Tv/Search CBL/SAT	Dual
CH Disc/Album+ CBL/SAT	Ch +	Music/Repeat CBL/SAT	Subt
CH Disc/Album- CBL/SAT	Ch -	Game/Random	AV
Menu/Prev CH CBL/SAT	Shift + Menu	Stereo/Play Mode CBL/SAT	Format
Top Menu/Guide CBL/SAT	Shift + Options	1 CBL/SAT	Shift + 1
Return CBL/SAT	Shift + Back	2 CBL/SAT	Shift + 2
Setup CBL/SAT	Shift + Smart	3 CBL/SAT	Shift + 3
Up CBL/SAT	Shift + Up	4 CBL/SAT	Shift + 4
Enter CBL/SAT	Shift + Ok	5 CBL/SAT	Shift + 5
Down CBL/SAT	Shift + Down	6 CBL/SAT	Shift + 6
Right CBL/SAT	Shift + Right	7 CBL/SAT	Shift + 7
Left CBL/SAT	Shift + Left	8 CBL/SAT	Shift + 8
Pause/Play rev. CBL/SAT	Shift + Pause	9 CBL/SAT	Shift + 9

Originalfernbedienung	Ersatzfernbedienung	Originalfernbedienung	Ersatzfernbedienung
0/ 11 CBL/ SAT	SHIFT + 0 Shift + 0		
DVD/ BD	SEARCH TV/R TV/ R		

Originalfernbedienung		Ersatzfernbedienung	
SOURCE	Power CD		Power
CH DISC	CH/Disc+ CD	CH	Ch +
ALBUM	CH/Disc- CD	CH	Ch -
RETURN	Return CD	RETURN BACK	Back
SETUP	Setup CD	HOME SMART	Smart
AUDIO HOME	Audio/Home CD	APP MEDIA	Media
	Up CD		Up
	Down CD		Down
PLAYLIST	Right CD		Right
PLAYLIST	Left CD		Left
ENTER	Enter CD	OK	Ok
	I<< CD		I<<
	>>I CD		>>I
	<< CD		<<
	>> CD		>>
	Play CD	PLAY MODE	Play
	Pause CD		Pause

Originalfernbedienung		Ersatzfernbedienung	
	Stop CD		Stop
SEARCH MOVIE/TV	Movie Tv/Search	A	Red
REPEAT MUSIC	Music/Repeat	B	Green
RANDOM GAME	Game/Random	C	Yellow
MODE THX	Stereo/Play Mode	D	Blue
1	1 CD	1	1
2	2 CD	2	2
3	3 CD	3	3
4	4 CD	4	4
5	5 CD	5	5
6	6 CD	6	6
7	7 CD	7	7
8	8 CD	8	8
9	9 CD	9	9
11 0	0/11 CD	0	0
+10 D.TUN DIMMER	+10/--/--10/D.Tu Dimmer CD	GUIDE	Guide
12 CLR SLEEP	CLR/Sleep/12	FAV PRE-CH	Pre Ch

Originalfernbedienung		Ersatzfernbedienung	
MUTING	Muting Receiver	MUTE	Mute
VOL	Vol + Receiver	+ VOL	Vol +
VOL	Vol - Receiver	VOL −	Vol -
TV/CD	TV/CD	SEARCH TV/R	TV/R

Originalfernbedienung	Ersatzfernbedienung

Originalfernbedienung		Ersatzfernbedienung	
ZONE2	Power Receiver Zone 2		Power
MUTING	Muting Receiver	MUTE	Mute
VOL +	Vol + Zone 2	VOL +	Vol +
VOL -	Vol - Zone 2	VOL -	Vol -
CH DISC +	CH Disc/Album+ Zone 2	CH +	Ch +
ALBUM -	CH Disc/Album- Zone 2	CH -	Ch -
	Up Zone 2		Up
ENTER	Enter Zone 2	OK	Ok
	Down Zone 2		Down
PLAYLIST	Right Zone 2		Right
PLAYLIST	Left Zone 2		Left
RETURN	Return Zone 2	RETURN BACK	Back
SETUP	Setup Zone 2	HOME SMART	Smart
AUDIO HOME	Audio/Home Zone	APP MEDIA	Media
	I<< Zone 2		I<<
	>>I Zone 2		>>I
	Play Zone 2	PLAY MODE	Play

Originalfernbedienung		Ersatzfernbedienung	
	>> Zone 2		>>
	<< Zone 2		<<
	Pause Zone 2		Pause
	Stop Zone 2		Stop
SEARCH MOVIE/TV	Movie Tv/Search Zone 2	A	Red
REPEAT MUSIC	Music/Repeat	B	Green
RANDOM GAME	Game/Random	C	Yellow
MODE THX	Stereo/Play Mode Zone 2	D	Blue
1	1 Zone 2	1	1
2	2 Zone 2	2	2
3	3 Zone 2	3	3
4	4 Zone 2	4	4
5	5 Zone 2	5	5
6	6 Zone 2	6	6
7	7 Zone 2	7	7
8	8 Zone 2	8	8
9	9 Zone 2	9	9

Originalfernbedienung		Ersatzfernbedienung	
11 0	0/ 11 Zone 2	0	0
-/-- 10 +10 D.TUN DIMMER	+10/ - - / - - 10/ D. Tu Di mmer Zone 2	-/-- GUIDE	Gui de
12 CLR SLEEP	CLR/ Sl eep/ 12	FAV PRE-CH	Pr e Ch

Originalfernbedienung	Ersatzfernbedienung