Original		Replacement	
Power	STANDBY	Power	STANDBY
Mute	MUTE	Mute / Dimmer	DIMMER MUTE
Play	▶II	Play / Slow	SLOW ▶
Pause	▶II	Pause / Step / Freeze	STEP-FREEZE II
Stop	■	Stop / Hold	HOLD ■
Rec	REC	Rec / Rec Mode	REC MODE
<<	◀◀	<< / Tune-	TUNE- ◀◀
>>	▶▶	>> / Tune+	TUNE+ ▶▶
I<<	I◀◀	I<< / Preset-	PRESET- I◀◀
>>I	▶▶I	>>I / Preset+	PRESET+ ▶▶I
S. Mode	S.Mode	Sound / Title	TITLE SOUND
Audio	AUDIO	Audio / Lang I/II	LANG I/II AUDIO
Subtitle	SUBTITLE	Subtitle / EQ	EQ SUBTITLE
P. Mode	P.Mode	Picture / Format	FORMAT PICTURE
Size	SIZE	Zoom / Size	SIZE ZOOM
Sleep	SLEEP	Sleep / Timer	TIMER SLEEP
Tv/Radio	TV/RADIO	TV/Radio / Program	PROGRAM TV/RADIO

Original		Replacement	
Index	INDEX	D.Menu / Top	TOP MENU D.MENU
Reveal	REVEAL	Setup / OPT /	OPT-TOOLS SETUP
Text	TEXT	Text / Goto	GOTO TEXT
AV/Source	SOURCE AV	AV / Input / RDS	RDS AV INPUT
Menu	MENU	Menu / Home	HOME MENU
Up	▲	Up	▲
i/Info	INFO i	Info / Angle	ANGLE INFO
Left	◀	Left	◀
OK	OK	OK	OK
Right	▶	Right	▶
Exit	EXIT	Exit / Cancel / Clear	CLEAR EXIT CANCEL
Down	▼	Down	▼
Back	↩	Back / Return	RETURN BACK
Vol +	VOL	Vol +	+ VOL
Rec List	REC LIST	Smart / List	LIST SMART
CH+	CH	CH+ / Page+	+ CH PAGE
Vol -	VOL	Vol -	− VOL

Original	Replacement	Original	Replacement
ATV	Display / Media	Blue	Blue / Prime Video / Random
CH-	CH- / Page-	Power/Display	Shift + Power
1	1	Hold	Shift + Stop /
2	2	Aspect	Shift + Picture / Format
3	3	USB	Shift + 8
4	4		
5	5		
6	6		
7	7		
8	8		
9	9		
Tv Guide	Guide / EPG / -/--		
0	0		
FAV	Fav / Marker / PC		
Red	Red / Netflix / Search		
Green	Green / APP / Repeat		
Yellow	Yellow / YouTube / Repeat		