Original		Replacement	
	Power		Power
	Mute		Mute
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	OK/Select		Ok
	M		Menu
	1		1
	2		2
	3		3
	4		4
	5		5
	6		6
	7		7
	8		8
	9		9

Original		Replacement	
	0		0
	-/--/EXIT		-/--
	Exit		Exit
	P<P/Swap		Pre Ch
	Vol +		Vol +
	Vol -		Vol -
	P+		Ch +
	P-		Ch -
	PP		Eject
	I-II		Dual
	Tv/DTV		TV/R
	[≡]		Text
	[≡O]		Options
	AV/Source		AV
	[≡+] / [X]		Format
	[≡X] / [■■]		3D
	[.≡] / [■]		Subt

Original		Replacement		Original		Replacement	
	[≡♦]		Media				
	[≡?]		Back				
	[≡i]		Info				
WIDE	Red/ [+] / Wide/ ↑		Red				
	Green/ ↓		Green				
	Yellow		Yellow				
GUIDE	Blue/ Guide		Blue				
	[i]		D. Menu				