Original		Replacement	
	Power		Power
	Eject	SURROUND	Eject / Surround
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD - STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX - HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
SHUFFLE	X/ Shuffle	RDS AV INPUT	AV / Input / RDS
0	0	HDMI - SAT 0	0
REPEAT	Repeat	SHIFT + APP REPEAT	Shift + Green / APP /
	Vol -	VOL −	Vol -
	Mute	DIMMER MUTE	Mute / Dimmer
	Vol +	+ VOL	Vol +

Original		Replacement	
MENU	Menu	HOME MENU	Menu / Home
	Home	SHIFT + HOME MENU	Shift + Menu /
BACK	Back	RETURN BACK	Back / Return
	Up		Up
	Left		Left
OK	OK	OK	OK
	Right		Right
	Down		Down
	Stop	HOLD	Stop / Hold
	Play/ Pause	SLOW	Play / Slow
INFO	Info	ANGLE INFO	Info / Angle
	<<	TUNE-	<< / Tune-
	>>	TUNE+	>> / Tune+
	I <<	PRESET-	I << / Preset-
	>>I	PRESET+	>>I / Preset+
	Red	NETFLIX SEARCH	Red / Netflix / Search
EPG	Green	APP REPEAT	Green / APP / Repeat

Original		Replacement		Original	Replacement
EPG	EPG	GUIDE EPG	Guide / EPG / -/--		
TXT	TXT	GOTO TEXT	Text / Goto		
TXT	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat		
	Blue	Prime Video RANDOM	Blue / Prime Video / Random		
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /		
TV SYS.	Tv Sys.	PROGRAM TV/RADIO	TV/Radio /		
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II		
SUBT.	Subt.	EQ SUBTITLE	Subtitle / EQ		
GOTO	→I / Goto	SHIFT +	Shift + Right		
SLOW	I>/ Slow	SHIFT + SLOW	Shift + Play /		
ANGLE	Angle	SHIFT + ANGLE INFO	Shift + Info / Angle		
ZOOM	Zoom	SIZE ZOOM	Zoom / Size		
REC	Rec	REC MODE	Rec / Rec Mode		
EDIT	Edit	TOP MENU D.MENU	D.Menu / Top		
COPY	Copy	FORMAT PICTURE	Picture / Format		
TIME SHIFT	Timeshift	TIMER SLEEP	Sleep / Timer		