| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| OPEN/ CLOSE | Open/Close | ZOOM | Eject |
| 1 | 1 | 1 | 1 |
| 2 | 2 | 2 | 2 |
| 3 | 3 | 3 | 3 |
| 4 | 4 | 4 | 4 |
| 5 | 5 | 5 | 5 |
| 6 | 6 | 6 | 6 |
| 7 | 7 | 7 | 7 |
| 8 | 8 | 8 | 8 |
| 9 | 9 | 9 | 9 |
| 0 | 0 | 0 | 0 |
| CLEAR | Clear | CLEAR EXIT | Exit |
| REPEAT | Repeat | REPEAT TEXT | Text |
| | Play | PLAY MODE | Play |
| | Stop | | Stop |
| | Pause | | Pause |

| Original | | Replacement | |
|---|---|---|---|
| | >> | | >> |
| | << | | << |
| | >>I | | >>I |
| | I<< | | I<< |
| DISC MENU | Disc Menu | E-MANUAL D.MENU | D. Menu |
| INFO/ MENU | Info/Menu | DISPLAY INFO | Info |
| BACK | Back | RETURN BACK | Back |
| HOME | Home | HOME SMART | Smart |
| TITLE/ POPUP | Title/Popup | SETTINGS OPT | Options |
| ENTER | Enter | OK | Ok |
| | Up | | Up |
| | Down | | Down |
| | Right | | Right |
| | Left | | Left |
| R | Red | A | Red |
| G | Green | B | Green |
| Y | Yellow | C | Yellow |

| Original | | Replacement | |
|---|---|---|---|
| B | Blue | D | Blue |
| | Power Tv | SHIFT + | Shift + Power |
| INPUT | Input Tv | TIMER AV | AV |
| VOL− | Vol- | VOL − | Vol - |
| VOL+ | Vol+ | + VOL | Vol + |

| Original | Replacement |
|---|---|
| | |