Original	Replacement	Original	Replacement
Power	Power	0	0
Up	Up	Exit/-/--	Exit
Down	Down	PP	Pre Ch
Right	Right	Swap/P<P	Smart
Left	Left	CH+	Ch +
OK/Select	Ok	CH-	Ch -
M	Menu	Vol +	Vol +
[i]/Info	Info	Vol -	Vol -
1	1	Mute	Mute
2	2	I-II	Dual
3	3	Tv/DTV	TV/R
4	4	AV/Source	AV
5	5	Red/↑	Red
6	6	Green/↓	Green
7	7	Yellow	Yellow
8	8	Blue	Blue
9	9	[≡]	Text

Original		Replacement		Original	Replacement
	[≡+] / [X]		For mat		
	[≡x] / [■■]		Subt		
	[≡o]		Opt i ons		
	[≡♦] / [+] / Wi de		3D		
	[. ≡] / [■]		Back		
	[≡?]		Medi a		
	Gui de/ [≡i]		Gui de		