| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | 0 | 0 |
| Up | Up | Exit/-/-- | Exit |
| Down | Down | PP | Pre Ch |
| Right | Right | Swap/P<P | Smart |
| Left | Left | CH+ | Ch + |
| OK/Select | Ok | CH- | Ch - |
| M | Menu | Vol + | Vol + |
| [ i ]/Info | Info | Vol - | Vol - |
| 1 | 1 | Mute | Mute |
| 2 | 2 | I-II | Dual |
| 3 | 3 | Tv/DTV | TV/R |
| 4 | 4 | AV/Source | AV |
| 5 | 5 | Red/↑ | Red |
| 6 | 6 | Green/↓ | Green |
| 7 | 7 | Yellow | Yellow |
| 8 | 8 | Blue | Blue |
| 9 | 9 | [≡] | Text |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| [ ≡+] / [ X] | Format | | |
| [ ≡x] / [ ■■] | Subt | | |
| [ ≡o] | Options | | |
| [ ≡♦] / [ +] / Wide | 3D | | |
| [ . ≡] / [ ■] | Back | | |
| [ ≡?] | Media | | |
| Guide/ [ ≡i ] | Guide | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |
| | | | |