| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Power | Power | Left | Left |
| Rec | Rec / Rec Mode | Up | Up |
| Red | Red / Netflix / Search | Right | Right |
| I << | I << / Preset- | OK | OK |
| Green/[ ] | Green / APP / Repeat | Down | Down |
| Stop | Stop / Hold | Vol + | Vol + |
| Yellow | Yellow / YouTube / Repeat | Mute | Mute / Dimmer |
| Play/[:≡] | Play / Slow | P+ | CH+ / Page+ |
| Blue/[ ■] | Blue / Prime Video / Random | Vol - | Vol - |
| >>I | >>I / Preset+ | Smart ♪ | Sound / Title |
| AV/[?] | AV / Input / RDS | P- | CH- / Page- |
| I-II/[≡I ≡] | Audio / Lang I/II | Smart [ ] | Smart / List |
| [<>]/[+] | Picture / Format | 1 | 1 |
| [-S-] | Zoom / Size | 2 | 2 |
| Menu | Menu / Home | 3 | 3 |
| [≡] | Text / Goto | 4 | 4 |
| Pause | Pause / Step / Freeze | 5 | 5 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 6 | 6 | TUNER 6 | 6 | | |
| 7 | 7 | AUX - HDD 7 | 7 | | |
| 8 | 8 | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| [i+] | [i+] | ANGLE INFO | Info / Angle | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| P•P | P<P | PC FAV MARKER | Fav / Marker / PC | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| O | Eject / Surround | [≡] | Text / Goto |
| -O- | Subtitle / EQ | Left | Left |
| Power | Power | Up | Up |
| Rec | Rec / Rec Mode | Right | Right |
| I<< | I<< / Preset- | OK | OK |
| Red | Red / Netflix / Search | Down | Down |
| Green/[[ ]] | Green / APP / Repeat | Vol + | Vol + |
| Stop | Stop / Hold | Mute | Mute / Dimmer |
| Play | Play / Slow | P+ | CH+ / Page+ |
| Yellow / List | Yellow / YouTube / Repeat | Vol - | Vol - |
| >>I | >>I / Preset+ | Smart ♪ | Sound / Title |
| AV/[?] | AV / Input / RDS | P- | CH- / Page- |
| I-II/[≡≡] | Audio / Lang I/II | Smart [ ] | Smart / List |
| [<>]/[+] | Zoom / Size | 1 | 1 |
| PIP [ ■] | Picture / Format | 2 | 2 |
| Menu | Menu / Home | 3 | 3 |
| Pause | Pause / Step / Freeze | 4 | 4 |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 5 | 5 | TAPE 5 | 5 | | |
| 6 | 6 | TUNER 6 | 6 | | |
| 7 | 7 | AUX - HDD 7 | 7 | | |
| 8 | 8 | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| [i+] | [i+] | ANGLE INFO | Info / Angle | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| P<P | P<P | PC FAV MARKER | Fav / Marker / PC | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |
| | | | | | |

| Original | | Replacement | |
|---|---|---|---|
| | Power | | Power |
| | -O- | EQ SUBTITLE | Subtitle / EQ |
| | I<< | PRESET- | I<< / Preset- |
| | >>I | PRESET+ | >>I / Preset+ |
| AV | AV/[?] | RDS AV INPUT | AV / Input / RDS |
| I-II | I-II/[≡] ≡] | LANG I/II AUDIO | Audio / Lang I/II |
| | [<>]/[+] | SIZE ZOOM | Zoom / Size |
| | Pause | STEP-FREEZE II | Pause / Step / Freeze |
| | [≡] | GOTO TEXT | Text / Goto |
| | Left | | Left |
| | Up | | Up |
| | Right | | Right |
| OK | OK | OK | OK |
| | Down | | Down |
| VOL + | Vol + | VOL + | Vol + |
| | Mute | DIMMER MUTE | Mute / Dimmer |
| P + | P+ | CH PAGE + | CH+ / Page+ |

| Original | | Replacement | |
|---|---|---|---|
| VOL – | Vol - | VOL – | Vol - |
| ♪ | Smart ♪ | TITLE SOUND | Sound / Title |
| P – | P- | CH PAGE – | CH- / Page- |
| | Smart [ ] | LIST SMART | Smart / List |
| 1 | 1 | TV 1 | 1 |
| 2 | 2 | DVD 2 | 2 |
| 3 | 3 | CD-STB 3 | 3 |
| 4 | 4 | VIDEO 4 | 4 |
| 5 | 5 | TAPE 5 | 5 |
| 6 | 6 | TUNER 6 | 6 |
| 7 | 7 | AUX-HDD 7 | 7 |
| 8 | 8 | USB 8 | 8 |
| 9 | 9 | BLUETOOTH 9 | 9 |
| 0 | 0 | HDMI-SAT 0 | 0 |
| P<P | P<P | PC FAV MARKER | Fav / Marker / PC |