Mandis shop

Panasonic N2QAYB000272

Original		Replacement	
BD	Power BD		Power
	Power Tv	SHIFT +	Shift + Power
CH	CH+ Tv	SHIFT + CH PAGE	Shift + CH+ /
VOL	Vol + Tv	VOL	Vol +
DRIVE SELECT	Drive Select	TOP MENU D.MENU	D. Menu / Top
AV	AV Tv	SHIFT + RDS AV INPUT	Shift + AV / Input / RDS
CH	CH- Tv	SHIFT + CH PAGE	Shift + CH- /
VOL	Vol - Tv	VOL	Vol -
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
PAGE CH	CH+	CH PAGE	CH+ / Page+
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
CH	CH-	CH PAGE	CH- / Page-
7	7	AUX-HDD 7	7

Original		Replacement	
8	8	USB 8	8
9	9	BLUETOOTH 9	9
PROG/CHECK	Prog/Check	PROGRAM TV/RADIO	TV/Radio /
DELETE *	Delete/*	SIZE ZOOM	Zoom / Size
0	0	HDMI-SAT 0	0
INPUT SELECT	Input Select	RDS AV INPUT	AV / Input / RDS
MANUAL SKIP	Manual Skip	FORMAT PICTURE	Picture / Format
	I << Skip	PRESET-	I << / Preset-
	Skip >>I	PRESET+	>>I / Preset+
	<< Slow/Search	TUNE-	<< / Tune-
	Slow/Search >>	TUNE+	>> / Tune+
STOP	Stop	HOLD	Stop / Hold
PAUSE	Pause	STEP-FREEZE	Pause / Step / Freeze
PLAY/x1.3	Play/x1.3	SLOW	Play / Slow
STATUS	i/Status	ANGLE INFO	Info / Angle
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--

Original		Replacement	
	Direct Navigator/Pop-up	LIST SMART	Smart / List
	Left/◁II		Left
OK	OK	OK	OK
	Up		Up
	Right/II▷		Right
FUNCTION MENU	Function/Menu	HOME MENU	Menu / Home
OPTION	Option	OPT-TOOLS SETUP	Setup / OPT /
	Down		Down
RETURN	Return	RETURN BACK	Back / Return
	Red	NETFLIX SEARCH	Red / Netflix / Search
	Green	APP REPEAT	Green / APP / Repeat
CREATE CHAPTER	Yellow/Create Chapter	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue	Prime Video RANDOM	Blue / Prime Video / Random
REC	Rec	REC MODE	Rec / Rec Mode
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec / Rec Mode
AUDIO	Audio	LANG I/II AUDIO	Audio / Lang I/II
DIRECT TV REC	Direct Tv Rec	SURROUND	Eject / Surround

Original		Replacement	
TEXT	Text	GOTO TEXT	Text / Goto
STTL	[≡♦]/Sttl	EQ SUBTITLE	Subtitle / EQ
DISPLAY	Display	MEDIA DISPLAY	Display / Media
TIME SLIP	Time Slip	TIMER SLEEP	Sleep / Timer