Original		Replacement	
	Power		Power
	Red	A	Red
	Green	B	Green
	Yellow	C	Yellow
	Blue	D	Blue
PAUSE LIVE TV	Play	PLAY MODE	Play
PAUSE LIVE TV	Pause/Pause Live		Pause
REC	Rec	REC MODE	Rec
STOP	Stop		Stop
PREV/REW	I<</PREV/REW		I<<
NEXT/FFW	>>I/Next/FFW		>>I
OPTIONS	Options	SETTINGS OPT	Options
DISC	Disc	TOP MENU MENU	Menu
HOME	Home	HOME SMART	Smart
BACK	Back	RETURN BACK	Back
	OK	OK	Ok
	Up		Up

Original		Replacement	
	Down		Down
	Right		Right
	Left		Left
	Wheel	APP MEDIA	Media
P	P+	CH +	Ch +
P	P-	CH -	Ch -
TV VOL	Tv Vol +	VOL +	Vol +
TV VOL	Tv Vol -	VOL -	Vol -
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement		Original		Replacement	
0	0	0	0				
AUDIO	Audio	SOUND DUAL	Dual				
SUBTITLE	Subtitle	AD SUBT	Subt				
INFO	Info	DISPLAY INFO	Info				
EDIT	Edit	CLEAR EXIT	Exit				
SCART	Scart	TIMER AV	AV				
LIVE TV	Live TV	SEARCH TV/R	TV/R				
HDD LIST	HDD List	DISC NAV LIST	List				
CAM	CAM	REPEAT TEXT	Text				
USB	USB	ECO 3D	3D				
SELECT	Select	E-MANUAL D.MENU	D. Menu				
TIMER GUIDE Plus+	Guide	-/-- GUIDE	Guide				