Original		Replacement	
DVD/VHS	Power		Power
DVD	DVD	HOME SMART	Smart
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
CANCEL/RESET	*Cancel / Reset	CLEAR EXIT	Exit
INPUT SELECT	Input Select	TIMER AV	AV
TRACKING/V-LOCK CH	Ch+Track/VLoc	+ CH	Ch +
CH	Ch- Track/VLock-	CH −	Ch -
AUDIO	Audio	SOUND DUAL	Dual

Original		Replacement	
ShowView	ShowView	AD SUBT	Subt
DIRECT TV REC	Direct Tv Rec	SEARCH TV/R	TV/R
SKIP/	I<< Skip/Index		I<<
INDEX	Skip/Index >>I		>>I
REW SEA	<< Slow/Search		<<
LOW/ ARCH FF	Slow/Search FF		>>
STOP	Stop		Stop
PAUSE	Pause		Pause
PLAY	Play	PLAY MODE	Play
DIRECT NAVIGATOR TOP MENU	Direct Navigator/Top	TOP MENU MENU	Menu
FUNCTIONS	Functions	SETTINGS OPT	Options
SUB MENU S	S/Sub Menu	E-MANUAL D.MENU	D. Menu
RETURN	Return	RETURN BACK	Back
	Up		Up
	Down		Down
	Right		Right
	Left		Left

Original		Replacement		Original	Replacement
ENTER	Enter	OK	Ok		
PROG/CHECK	Prog/Check	PROG SLEEP	Sleep		
DISPLAY	Display	DISPLAY INFO	Info		
STATUS	Status	B	Green		
TIME SLIP JET REW	<< Jet Rew / Time Slip	PICTURE FORMAT	Format		
REC	Rec	REC MODE	Rec		
REC MODE	Rec Mode	SHIFT + REC MODE	Shift + Rec		
EXT LINK	Ext Link	APP MEDIA	Media		
TIMER	Timer	SHIFT + TIMER AV	Shift + AV		
DVD ERASE C	Dvd Erase C	D	Blue		
CREATE CHAPTER	Create Chapter	C	Yellow		