Original		Replacement	
	Power		Power
	Red/ Sound↑	NETFLIX SEARCH	Red / Netflix / Search
	Red/ Sound↑	TITLE SOUND	Sound / Title
	Green/ Picture/ ↓	APP REPEAT	Green / APP / Repeat
	Green/ Picture/ ↓	FORMAT PICTURE	Picture / Format
	Yellow/ Feature	YouTube REPEAT A-B	Yellow / YouTube / Repeat
	Blue/ Install	Prime Video RANDOM	Blue / Prime Video / Random
	[≡]	GOTO TEXT	Text / Goto
	[≡0]	SLOW	Play / Slow
	[≡+]	HOLD	Stop / Hold
	[≡x] / [· ·]	STEP-FREEZE	Pause / Step / Freeze
	[/≡] / [*]	REC MODE	Rec / Rec Mode
	[+] ([≡♦] / Wide	SIZE ZOOM	Zoom / Size
	[≡?] / PC	PC FAV MARKER	Fav / Marker / PC
	[≡i] / Guide	-/-- GUIDE EPG	Guide / EPG / -/--
	1	TV 1	1
	2	DVD 2	2

Original		Replacement	
	3	CD-STB 3	3
	4	VIDEO 4	4
	5	TAPE 5	5
	6	TUNER 6	6
	7	AUX-HDD 7	7
	8	USB 8	8
	9	BLUETOOTH 9	9
	P<P	MEDIA DISPLAY	Display / Media
	0	HDMI-SAT 0	0
	-/-- EXIT	SHIFT + -/-- GUIDE EPG	Shift + Guide / EPG / -/--
	Vol -	VOL −	Vol -
	Vol +	+ VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
	P-	CH PAGE −	CH- / Page-
	P+	+ CH PAGE	CH+ / Page+
	[i] / Info	ANGLE INFO	Info / Angle
	TV/ DTV	PROGRAM TV/ RADIO	TV/ Radio / Program

Original	Replacement	Original	Replacement
AV	AV / Input / RDS		
I-II	Audio / Lang I/II		
PP	Back / Return		
Up	Up		
Left	Left		
OK/Select	OK		
Right	Right		
M	Menu / Home		
Down	Down		