Original	Replacement
Power	Power
Open/Close	Eject
CD/FM	Yellow
Dock	Blue
Audio In/USB	Red
Preset/Album	Up
Preset/Album	Down
>>I	>>I
>>I	Right
I<<	I<<
I<<	Left
OK	Ok
Vol +	Vol +
Vol -	Vol -
Mute	Mute
Play	Play
Pause	Pause

Original	Replacement
Stop	Stop
Menu	Menu
RDS/Display	Info
Repeat/Shuffle	Text
Prog	Shift + Sleep
Sound	Dual
Clock	AV
Sleep/Timer	Sleep

Original	Replacement
Power	Power
Open/Close	Eject
CD/FM	Yellow
Dock	Blue
Audio In/USB	Red
Preset/Album	Up
Preset/Album	Down
>>I	>>I
>>I	Right
I<<	I<<
I<<	Left
OK	Ok
Vol +	Vol +
Vol -	Vol -
Mute	Mute
Play	Play
Pause	Pause

Original	Replacement
Stop	Stop
Menu	Menu
RDS/Display	Info
Repeat/Shuffle	Text
Prog	Shift + Sleep
Sound	Dual
Clock	AV
Sleep/Timer	Sleep

Original		Replacement	
	Power		Power
	Open/Close	ZOOM	Eject
FM CD	CD/FM	C	Yellow
AUDIO IN USB	Audio In/USB	A	Red
DOCK	Dock	D	Blue
PRESET/ALBUM	Preset/Album		Up
	Preset/Album		Down
	>>I		>>I
	>>I		Right
	I <<		I <<
	I <<		Left
OK	OK	OK	Ok
VOL +	Vol +	VOL +	Vol +
VOL −	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute
	Play	PLAY MODE	Play
	Pause		Pause

Original		Replacement	
MENU	Stop		Stop
MENU	Menu	TOP MENU MENU	Menu
DISPLAY RDS	RDS/Display	DISPLAY INFO	Info
SHUFFLE REPEAT	Repeat/Shuffle	REPEAT TEXT	Text
PROG	Prog	SHIFT + PROG SLEEP	Shift + Sleep
SOUND	Sound	SOUND DUAL	Dual
CLOCK	Clock	TIMER AV	AV
TIMER SLEEP	Sleep/Timer	PROG SLEEP	Sleep