Original	Replacement	Original	Replacement
System Power	Power	Tape	Shift + 5
System Power Off	Shift + Power	MD	Shift + 4
Source On/Off	Red / Netflix / Search	1 Tuner	1
Source On/Off	Green / APP / Repeat	2 Tuner	2
Source On/Off	Blue / Prime Video / Random	3 Tuner	3
Source On/Off CD	Yellow / YouTube / Repeat	A. F/P Tuner	Guide / EPG / -/--
Source On/Off	Shift + Red / Netflix /	4 Tuner	4
Source On/Off	Shift + Green / APP /	5 Tuner	5
Source On/Off	Shift + Yellow / YouTube /	6 Tuner	6
Source On/Off MD	Shift + Blue / Prime	B. -/-- Tuner	Fav / Marker / PC
Source On/Off	Shift + Fav / Marker / PC	7 Tuner	7
Phono	Shift + 1	8 Tuner	8
CD	Shift + 3	9 Tuner	9
Tuner	Shift + 6	Mode Tuner	Smart / List
CD-R	Shift + 2	- Tuner	CH- / Page-
AUX1	Shift + 7	0 Tuner	0
AUX2	Shift + 8	+ Tuner	CH+ / Page+

Original		Replacement		Original	Replacement
MEMO	Memo Tuner	MEDIA DISPLAY	Display / Media		
SCROLL	Scroll Tuner	RETURN BACK	Back / Return		
CANCEL	Cancel Tuner	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
1-MOD TEXT	Text / Mode 1	GOTO TEXT	Text / Goto		
ODE-2 TIME	Time/Mode 2	TIMER SLEEP	Sleep / Timer		
⏮	I<< Tuner	PRESET- ⏮	I<< / Preset-		
⏭	>>I Tuner	PRESET+ ⏭	>>I / Preset+		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
◀◀	<< Tuner	TUNE- ◀◀	<< / Tune-		
▶▶	>> Tuner	TUNE+ ▶▶	>> / Tune+		
▲ VOLUME	Vol +	+ VOL	Vol +		
VOLUME ▼	Vol -	VOL −	Vol -		

Original	Replacement	Original	Replacement
System Power	Power	Tape	Shift + 5
System Power Off	Shift + Power	MD	Shift + 4
Source On/Off	Shift + Red / Netflix /	1 CDR	1
Source On/Off	Red / Netflix / Search	2 CDR	2
Source On/Off	Green / APP / Repeat	3 CDR	3
Source On/Off CD	Yellow / YouTube / Repeat	4 CDR	4
Source On/Off	Blue / Prime Video / Random	5 CDR	5
Source On/Off	Shift + Green / APP /	6 CDR	6
Source On/Off	Shift + Yellow / YouTube /	7 CDR	7
Source On/Off MD	Shift + Blue / Prime	8 CDR	8
Source On/Off	Shift + Fav / Marker / PC	9 CDR	9
Phono	Shift + 1	Mode CDR	Smart / List
CD	Shift + 3	- CDR	CH- / Page-
Tuner	Shift + 6	0 CDR	0
CD-R	Shift + 2	+ CDR	CH+ / Page+
AUX1	Shift + 7	Memo CDR	Display / Media
AUX2	Shift + 8	Scroll CDR	Back / Return

Original		Replacement		Original	Replacement
CANCEL	Cancel CDR	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
1~MOD TEXT	Text / Mode 1	GOTO TEXT	Text / Goto		
ODE~2 TIME	Time / Mode 2	TIMER SLEEP	Sleep / Timer		
⏮	I<< CDR	PRESET- ⏮	I<< / Preset-		
▶	Play CDR	SLOW ▶	Play / Slow		
⏭	>>I CDR	PRESET+ ⏭	>>I / Preset+		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
◀◀	<< CDR	TUNE- ◀◀	<< / Tune-		
■	Stop CDR	HOLD ■	Stop / Hold		
▶▶	>> CDR	TUNE+ ▶▶	>> / Tune+		
▲ VOLUME	Vol +	+ VOL	Vol +		
⏸	Pause CDR	STEP-FREEZE ⏸	Pause / Step / Freeze		
OPEN/ CLOSE	Open/Close	SURROUND ⏏	Eject / Surround		
VOLUME ▼	Vol -	VOL −	Vol -		

Original	Replacement
System Power	Power
System Power Off	Shift + Power
Source On/Off	Shift + Yellow / YouTube /
Source On/Off	Red / Netflix / Search
Source On/Off	Green / APP / Repeat
Source On/Off CD	Yellow / YouTube / Repeat
Source On/Off	Blue / Prime Video / Random
Source On/Off	Shift + Red / Netflix /
Source On/Off	Shift + Green / APP /
Source On/Off MD	Shift + Blue / Prime
Source On/Off	Shift + Fav / Marker / PC
Phono	Shift + 1
CD	Shift + 3
Tuner	Shift + 6
CD-R	Shift + 2
AUX1	Shift + 7
AUX2	Shift + 8

Original	Replacement
Tape	Shift + 5
MD	Shift + 4
1 Tape	1
2 Tape	2
3 Tape	3
A. F/P Tape	Guide / EPG / -/--
4 Tape	4
5 Tape	5
6 Tape	6
B. -/-- Tape	Fav / Marker / PC
7 Tape	7
8 Tape	8
9 Tape	9
Mode Tape	Smart / List
- Tape	CH- / Page-
0 Tape	0
+ Tape	CH+ / Page+

Original		Replacement		Original	Replacement
MEMO	Memo Tape	MEDIA DISPLAY	Display / Media		
CANCEL	Cancel Tape	CLEAR EXIT CANCEL	Exit / Cancel / Clear		
1-MOD TEXT	Text / Mode 1	GOTO TEXT	Text / Goto		
ODE-2 TIME	Time / Mode 2	TIMER SLEEP	Sleep / Timer		
I<<	I<< Tape	PRESET- I<<	I<< / Preset-		
▶	Play Tape	SLOW ▶	Play / Slow		
>>I	>>I Tape	PRESET+ >>I	>>I / Preset+		
MUTE	Mute	DIMMER MUTE	Mute / Dimmer		
<<	<< Tape	TUNE- <<	<< / Tune-		
■	Stop Tape	HOLD ■	Stop / Hold		
>>	>> Tape	TUNE+ >>	>> / Tune+		
VOLUME ▲	Vol +	VOL +	Vol +		
◀▶	<> Tape	REC MODE ●	Rec / Rec Mode		
II	Pause Tape	STEP-FREEZE II	Pause / Step / Freeze		
OPEN/ CLOSE	Open/Close	SURROUND ⏏	Eject / Surround		
VOLUME ▼	Vol -	VOL −	Vol -		

Original		Replacement		Original		Replacement	
SYSTEM ON	System Power		Power	TAPE	Tape	SHIFT + TAPE 5	Shift + 5
POWER OFF	System Power Off	SHIFT +	Shift + Power	MD	MD	SHIFT + VIDEO 4	Shift + 4
SOURCE ON/OFF	Source On/Off	NETFLIX SEARCH	Red / Netflix / Search	1	1 CD	TV 1	1
SOURCE ON/OFF	Source On/Off CD	YouTube REPEAT A-B	Yellow / YouTube / Repeat	2	2 CD	DVD 2	2
SOURCE ON/OFF	Source On/Off	APP REPEAT	Green / APP / Repeat	3	3 CD	CD-STB 3	3
SOURCE ON/OFF	Source On/Off	Prime Video RANDOM	Blue / Prime Video / Random	A.F/P	A. F/P CD	-/-- GUIDE EPG	Guide / EPG / -/--
SOURCE ON/OFF	Source On/Off	SHIFT +	NETFLIX SEARCH Shift + Red / Netflix /	4	4 CD	VIDEO 4	4
SOURCE ON/OFF	Source On/Off	SHIFT +	APP REPEAT Shift + Green / APP /	5	5 CD	TAPE 5	5
SOURCE ON/OFF	Source On/Off	SHIFT +	YouTube REPEAT A-B Shift + Yellow / YouTube /	6	6 CD	TUNER 6	6
SOURCE ON/OFF	Source On/Off MD	SHIFT +	Prime Video RANDOM Shift + Blue / Prime	B.-/--	B. -/-- CD	PC FAV MARKER	Fav / Marker / PC
SOURCE ON/OFF	Source On/Off	SHIFT +	PC FAV MARKER Shift + Fav / Marker / PC	7	7 CD	AUX-HDD 7	7
PHONO	Phono	SHIFT +	TV 1 Shift + 1	8	8 CD	USB 8	8
CD	CD	SHIFT +	CD-STB 3 Shift + 3	9	9 CD	BLUETOOTH 9	9
TUNER	Tuner	SHIFT +	TUNER 6 Shift + 6	MODE	Mode CD	LIST SMART	Smart / List
CD-R	CD-R	SHIFT +	DVD 2 Shift + 2	-	- CD	CH PAGE -	CH- / Page-
AUX 1	AUX1	SHIFT +	AUX-HDD 7 Shift + 7	0	0 CD	HDMI-SAT 0	0
AUX 2	AUX2	SHIFT +	USB 8 Shift + 8	+	+ CD	+ CH PAGE	CH+ / Page+

Original		Replacement		Original		Replacement	
MEMO	Memo CD	MEDIA DISPLAY	Display / Media				
SCROLL	Scroll CD	RETURN BACK	Back / Return				
CANCEL	Cancel CD	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
1~MODE TEXT	Text / Mode 1 CD	GOTO TEXT	Text / Goto				
ODE~2 TIME	Time / Mode 2 CD	TIMER SLEEP	Sleep / Timer				
⏮	I<< CD	PRESET- ⏮	I<< / Preset-				
▶	Play CD	SLOW ▶	Play / Slow				
⏭	>>I CD	PRESET+ ⏭	>>I / Preset+				
MUTE	Mute	DIMMER MUTE	Mute / Dimmer				
◀◀	<< CD	TUNE- ◀◀	<< / Tune-				
■	Stop CD	HOLD ■	Stop / Hold				
▶▶	>> CD	TUNE+ ▶▶	>> / Tune+				
VOLUME ▲	Vol +	VOL +	Vol +				
❚❚	Pause CD	STEP-FREEZE ❚❚	Pause / Step / Freeze				
OPEN/ CLOSE	Open/Close CD	SURROUND ⏏	Eject / Surround				
VOLUME ▼	Vol -	VOL −	Vol -				