Original		Replacement	
	Power		Power
	Up		Up
	Left		Left
	Right		Right
	Down		Down
M	M	HOME MENU	Menu / Home
[i]	[i]	ANGLE INFO	Info / Angle
OK	OK	OK	OK
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9

Original		Replacement	
PP	PP	RETURN BACK	Back / Return
0	0	HDMI-SAT 0	0
-/--	-/--	-/-- GUIDE EPG	Guide / EPG / -/--
P<P	P<P	PC FAV MARKER	Fav / Marker / PC
P/CH-	P/CH-	CH PAGE −	CH- / Page-
P/CH+	P/CH+	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol -
	Vol +	+ VOL	Vol +
	Mute	DIMMER MUTE	Mute / Dimmer
I-II	I-II	LANG I/II AUDIO	Audio / Lang I/II
TV	TV	LIST SMART	Smart / List
AV	AV	RDS AV INPUT	AV / Input / RDS
SOUND	Red/Sound	NETFLIX SEARCH	Red / Netflix / Search
SOUND	Red/Sound	TITLE SOUND	Sound / Title
PICTURE	Green/Picture	APP REPEAT	Green / APP / Repeat
PICTURE	Green/Picture	FORMAT PICTURE	Picture / Format
FEATURE	Yellow/Feature	YouTube REPEAT A-B	Yellow / YouTube / Repeat

Original	Replacement	Original	Replacement
INSTALL Blue/Install	Prime Video RANDOM Blue / Prime Video / Random		
[≡]	GOTO TEXT Text / Goto		
[≡o]	TIMER SLEEP Sleep / Timer		
[≡+]	HOLD Stop / Hold		
[≡x] / [· ·]	TUNE- << / Tune-		
[/≡] / [*]	SLOW Play / Slow		
[≡◆] / [+]	STEP-FREEZE Pause / Step / Freeze		
[≡?] / PC	SHIFT + PC FAV MARKER Shift + Fav / Marker / PC		
[≡i]	TUNE+ >> / Tune+		