Original		Replacement	
	Power		Power
	Tv/Radio	PROGRAM TV/RADIO	TV/Radio /
SUBTITLE	Subtitle	EQ SUBTITLE	Subtitle / EQ
PIP/* AD	AD/PIP/*	MEDIA DISPLAY	Display / Media
TV/PC	Tv/PC	SHIFT +	PROGRAM TV/RADIO Shift + TV/Radio / Program
	Source	RDS AV INPUT	AV / Input / RDS
1	1	TV 1	1
2	2	DVD 2	2
3	3	CD-STB 3	3
4	4	VIDEO 4	4
5	5	TAPE 5	5
6	6	TUNER 6	6
7	7	AUX-HDD 7	7
8	8	USB 8	8
9	9	BLUETOOTH 9	9
LIST	List	LIST SMART	Smart / List
0	0	HDMI-SAT 0	0

Original		Replacement	
Q.VIEW	Q.View	FORMAT PICTURE	Picture / Format
	Vol +	+ VOL	Vol +
FAV	Fav	PC FAV MARKER	Fav / Marker / PC
P PAGE	P+	+ CH PAGE	CH+ / Page+
	Vol -	VOL −	Vol -
GUIDE	Guide	-/-- GUIDE EPG	Guide / EPG / -/--
P PAGE	P-	CH PAGE −	CH- / Page-
	Mute	DIMMER MUTE	Mute / Dimmer
TEXT	Text	GOTO TEXT	Text / Goto
	Home	HOME MENU	Menu / Home
T.OPT	T.Opt	SHIFT +	OPT-TOOLS SETUP Shift + Setup / OPT / Tools
	☼	OPT-TOOLS SETUP	Setup / OPT /
	Up		Up
Q.MENU	Q.Menu	TOP MENU D.MENU	D.Menu / Top
	Left		Left
OK	Ok	OK	OK
	Right		Right

Original		Replacement		Original		Replacement	
BACK	Back	RETURN BACK	Back / Return				
▼	Down	▼	Down				
EXIT	Exit	CLEAR EXIT CANCEL	Exit / Cancel / Clear				
INFO	Info	ANGLE INFO	Info / Angle				
■	Stop	HOLD ■	Stop / Hold				
◀◀	<<	TUNE- ◀◀	<< / Tune-				
▶	Play	SLOW ▶	Play / Slow				
❚❚	Pause	STEP-FREEZE ❚❚	Pause / Step / Freeze				
▶▶	>>	TUNE+ ▶▶	>> / Tune+				
●	Red	NETFLIX SEARCH	Red / Netflix / Search				
●●	Green	APP REPEAT	Green / APP / Repeat				
●●	Yellow	YouTube REPEAT A-B	Yellow / YouTube / Repeat				
●●	Blue	Prime Video RANDOM	Blue / Prime Video / Random				