Original	Replacement	Original	Replacement
Power Receiver	Power	Vol -	Vol -
Power DVD	Shift + Power	Tone	Pre Ch
Sleep	Sleep	Sound	Shift + Dual
Input Mode	AV	Dimmer	3D
Setup	Options	Listen Mode	TV/R
1	1	Active EQ	Red
2	2	Multi Control	Ch -
3	3	Multi Control U	Ch +
4	4	Mute	Mute
5	5	Play/Pause/Ban	Play
6	6	Stop/Auto/Mono	Stop
7	7	I<</P. Call	I<<
8	8	>>I/P. Cal	>>I
9	9	<< Tuning	<<
0	0	>> Tuning	>>
+10	Guide	Bass Boost	Green
Vol +	Vol +	Loudness	Eject

Original		Replacement	
TUNER	Tuner	APP MEDIA	Media
VIDEO	Video	C	Yellow
GAME/F.AUX	Game/F. Aux	DISPLAY INFO	Info
AUX	AUX	HOME SMART	Smart
DVD	DVD	SHIFT + HOME SMART	Shift + Smart
1	1 DVD	SHIFT + 1	Shift + 1
2	2 DVD	SHIFT + 2	Shift + 2
3	3 DVD	SHIFT + 3	Shift + 3
4	4 DVD	SHIFT + 4	Shift + 4
5	5 DVD	SHIFT + 5	Shift + 5
6	6 DVD	SHIFT + 6	Shift + 6
7	7 DVD	SHIFT + 7	Shift + 7
8	8 DVD	SHIFT + 8	Shift + 8
9	9 DVD	SHIFT + 9	Shift + 9
0	0 DVD	SHIFT + 0	Shift + 0
+10	+10 DVD	SHIFT + -/-- GUIDE	Shift + Guide
MENU	Menu DVD	TOP MENU MENU	Menu

Original		Replacement	
ENTER	Enter DVD	OK	Ok
TOP MENU	Top Menu DVD	SHIFT + TOP MENU MENU	Shift + Menu
	Up DVD		Up
	Down DVD		Down
	Right DVD		Right
	Left DVD		Left
RETURN	Return DVD	RETURN BACK	Back
ON SCREEN	On Screen DVD	DISC NAV LIST	List
SETUP	Setup DVD	SHIFT + SETTINGS OPT	Shift + Options
BAND ▶/II	Play/Pause DVD	SHIFT + PLAY MODE ▶	Shift + Play
DIMMER	Dimmer DVD	SHIFT + ECO 3D	Shift + 3D
AUTO/MONO ■	Stop DVD	SHIFT + ■	Shift + Stop
II	Pause DVD	II	Pause
TUN ◀◀	<< DVD	SHIFT + ≪	Shift + <<
WING ▶▶	>> DVD	SHIFT + ≫	Shift + >>
P.C ⏮	I<< DVD	SHIFT + ⏮	Shift + I<<
CALL ⏭	>>I DVD	SHIFT + ⏭	Shift + >>I

Original		Replacement		Original	Replacement
DISC SEL.	Disc Sel	E-MANUAL D.MENU	D. Menu		
DISC SKIP	Disk Skip	D	Blue		
SUBTITLE	Subtile	AD SUBT	Subt		
AUDIO	Audio	SOUND DUAL	Dual		
ANGLE	Angle	PICTURE FORMAT	Format		
REPEAT	Repeat	REPEAT TEXT	Text		