Mandis shop

JVC RM-RXQ1002

Original		Replacement	
1	1	1	1
2	2	2	2
3	3	3	3
(AC) POWER	(AC) Power		Power
4	4	4	4
5	5	5	5
6	6	6	6
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
7	7	7	7
8	8	8	8
9	9	9	9
DISPLAY	Display	MEDIA DISPLAY	Display / Media
10	10	0	0
+10	+10	GUIDE EPG	Guide / EPG / -/--
AUTO PRESET	Auto Preset	ANGLE INFO	Info / Angle
INTRO	Intro	OK	OK
REPEAT	Repeat	APP REPEAT	Green / APP / Repeat

Original		Replacement	
PROGRAM	Program	SHIFT + PROGRAM TV/RADIO	Shift + TV/Radio / Program
■/CLEAR	Stop	HOLD ■	Stop / Hold
■/CLEAR	Clear	CLEAR EXIT CANCEL	Exit / Cancel / Clear
►/II	Play	SLOW ►	Play / Slow
►/II	Pause	STEP-FREEZE II	Pause / Step / Freeze
OPEN/CLOSE	Open/Close	SURROUND ⏏	Eject / Surround
BAND	Tuner Band	PROGRAM TV/RADIO	TV/Radio /
STEREO AUTO/MONO	Stereo/Auto/mono	TITLE SOUND	Sound / Title
⏮ SEA DOWN	I<< Search	PRESET- ⏮	I<< / Preset-
⏮ SEA DOWN	Down	▼	Down
ARCH ⏭ UP	Search >>I	PRESET+ ⏭	>>I / Preset+
ARCH ⏭ UP	Up	▲	Up
BASS	Bass	LANG I/II AUDIO	Audio / Lang I/II
TONE	Tone	FORMAT PICTURE	Picture / Format
— VOLU	Vol -	VOL —	Vol -
LUME +	Vol +	+ VOL	Vol +

https://al-remotecontrols.nl/en/JVC-RM-RXQ1002-replacement-remote-control-for-JVC-RM-RXQ1002-RM-RXQ1001.htm