Original	Replacement
On/Standby	Power
Memory	Menu
Clear/Dimmer	Exit
Select Disc 1	Shift + 1
Select Disc 2	Shift + 2
Select Disc 3	Shift + 3
Select Disc 4	Shift + 4
Select Disc 5	Shift + 5
Random CD	Media
Pause CD	Pause
Stop CD	Stop
Play CD	Play
CD	Yellow
Tuner (Band)	Green
Tape (1-2)	Blue
Audio In	Red
Play Tape	Shift + Play

Original	Replacement
Rec/Pause Tape	Rec
Stop Tape	Shift + Stop
Tuning/Cursor Up	Up
Tuning/Cursor Down	Down
Tuning/Cursor Right/Preset	Right
Tuning/Cursor Left/Preset Down	Left
Navigation	List
Character	Smart
Display	Info
Enter	Ok
Clock/Timer	AV
RDS ASPM	TV/R
RDS PTY	Format
RDS Display	3D
1	1
2	2
3	3

Original		Replacement	
GHI 4	4	4	4
JKL 5	5	5	5
MNO 6	6	6	6
PQRS 7	7	7	7
TUV 8	8	8	8
WXYZ 9	9	9	9
SPACE 0	0	0	0
+10	+10	GUIDE	Guide
VOLUME +	Vol +	VOL +	Vol +
VOLUME −	Vol -	VOL −	Vol -
X-BASS /DEMO	X. Bass/Demo	AD SUBT	Subt
EQUALIZER MODE	Equalizer Mode	SOUND DUAL	Dual

Original	Replacement