Mandis shop

Teac RC-1195

Original		Replacement
STANDBY/ON	Standby / On	Power
	Dimmer	OK
FUNCTION	Function	SETTINGS OPT
TIMER	Timer	TIMER AV
SLEEP	Sleep	PROG SLEEP
FM/AM	FM / AM	HOME SMART
SHUFFLE FM MODE	FM Mode / Shuffle	SEARCH TV/R
REPEAT PTY	PTY / Repeat	REPEAT TEXT
MP3 RDS	RDS / MP3	APP MEDIA
TUNI	I<< / Tuning -	I<<
JNING	>>I / Tuning +	>>I
PLAY/PAUSE	Play / Pause	PLAY MODE ▶
PLAY/PAUSE	Play / Pause	Pause
PRESET/F	Preset/Folder	CH −
T/FOLDER	Preset/Folder Up	+ CH
STOP	Stop	Stop
BASS	Bass	Left

Original		Replacement
TREBLE	Treble	Right
VOLUME	Volume (Bass/Treble) +	+ VOL
	Volume (Bass/Treble) -	VOL −
MEMORY/ TIME SET	Memory / Time	TOP MENU MENU
MUTING	Muting	MUTE

https://all-remote-controls.nl/en/Teac/1058323-46292-replacement-remote-control-for-Teac-RC-1195.html