Original		Replacement	
POWER	Power		Power
TV	Tv	SEARCH TV/R	TV/R
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
FAV.CH	FAV CH	SHIFT + FAV PRE-CH	Shift + Pre Ch
PRE-CH	PRE CH	FAV PRE-CH	Pre Ch
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -
MUTE	Mute	MUTE	Mute

Original		Replacement	
SOURCE	Source	TIMER AV	AV
P	P +	+ CH	Ch +
P	P -	CH −	Ch -
INFO	Info	DISPLAY INFO	Info
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
RETURN	Return	RETURN BACK	Back
	Up		Up
	Right		Right
	Down		Down
	Left		Left
	Enter	OK	Ok
CH LIST	CH LIST	DISC NAV LIST	List
EXIT	Exit	CLEAR EXIT	Exit
	Red	A	Red
	Green	B	Green

Original		Replacement		Original	Replacement
	Yellow	C	Yellow		
	Blue	D	Blue		
TTX/MIX	TTX/MIX	REPEAT TEXT	Text		
SRS	SRS	APP MEDIA	Media		
P.SIZE	P SIZE	PICTURE FORMAT	Format		
I-II DUAL	Dual I/II	SOUND DUAL	Dual		
AD	AD	SHIFT + AD SUBT	Shift + Subt		
SUBT.	SUBT	AD SUBT	Subt		
<<	<<	<<	<<		
<<	<<	<<	I <<		
Pause	Pause	Pause	Pause		
>>	>>	>>	>>		
>>	>>	>>I	>>I		
Rec	Rec	REC MODE	Rec		
Play	Play	PLAY MODE	Play		
Stop	Stop	Stop	Stop		