Original		Replacement	
	Power		Power
INPUT	Input	TIMER AV	AV
Sport	Sport	SEARCH TV/R	TV/R
P.Mode	P. Mode	PICTURE FORMAT	Format
S.Mode	S. Mode	SHIFT + SOUND DUAL	Shift + Dual
SLEEP	Sleep	PROG SLEEP	Sleep
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
GUIDE	Guide	-/-- GUIDE	Guide

Original		Replacement	
INFO	Info	DISPLAY INFO	Info
VOL	Vol +	+ VOL	Vol +
VOL	Vol -	VOL −	Vol -
	Mute	MUTE	Mute
CH.List	CH. List	DISC NAV LIST	List
	Home	HOME SMART	Smart
CH	CH+	+ CH	Ch +
CH	CH-	CH −	Ch -
	☼	TOP MENU MENU	Menu
	[≡]	SETTINGS OPT	Options
BACK	Back	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok

Original		Replacement		Original	Replacement
A	Red	A	Red		
B	Green	B	Green		
C	Yellow	C	Yellow		
D	Blue	D	Blue		
<<	<<	<<	<<		
Play	Play	PLAY MODE	Play		
>>	>>	>>	>>		
Stop	Stop	Stop	Stop		
Pause	Pause	Pause	Pause		
Rec	Rec	REC MODE	Rec		
Subtitle	Subtitle	AD SUBT	Subt		
Language	Language	SOUND DUAL	Dual		
[++]	[++]	ECO 3D	3D		
TXT	TXT	REPEAT TEXT	Text		
YouTube	YouTube	SHIFT + APP MEDIA	Shift + Media		
NETFLIX	Netflix	SHIFT + HOME SMART	Shift + Smart		
Media	Media	APP MEDIA	Media		