Original		Replacement	
POWER	Power		Power
SOURCE	Source	TIMER AV	AV
HDMI	HDMI	HOME SMART	Smart
1	1	1	1
abc 2	2	2	2
def 3	3	3	3
ghi 4	4	4	4
jkl 5	5	5	5
mno 6	6	6	6
pqrs 7	7	7	7
tuv 8	8	8	8
wxyz 9	9	9	9
0	0	0	0
TEXT TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
	Vol +	+ VOL	Vol +
	Vol -	VOL −	Vol -

Original		Replacement	
MUTE	Mute	MUTE	Mute
CH LIST	CH. List	DISC NAV LIST	List
	P+	+ CH	Ch +
	P-	CH −	Ch -
MEDIA.P	Media. P	APP MEDIA	Media
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
INFO	Info	DISPLAY INFO	Info
RETURN BACK	Return/Back	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
OK	OK	OK	Ok
A	Red	A	Red

Original		Replacement		Original	Replacement
B	Green	B	Green		
C	Yellow	C	Yellow		
D	Blue	D	Blue		
P.MODE	P. Mode	PICTURE FORMAT	Format		
S.MODE	S. Mode	SHIFT + SOUND DUAL	Shift + Dual		
I-II DUAL	Dual / I - II	SOUND DUAL	Dual		
D	D	E-MANUAL D.MENU	D. Menu		
P.SIZE	P. Size	ECO 3D	3D		
SUBT.	SUBT.	AD SUBT	Subt		
<<	<<	<<	<<		
Pause	Pause	Pause	Pause		
>>	>>	>>	>>		
Rec	Rec	REC MODE	Rec		
Play	Play	PLAY MODE	Play		
Stop	Stop	Stop	Stop		