Mandis shop

Onkyo RC762M- Receiver - VCR/ DVR- CBL/ SAT- Game- Aux- Tuner

Original	Replacement	Original	Replacement
On / Standby	Power	Vol +	Vol +
Display	Info	Vol -	Vol -
Input BD/ DVD	Shift + 1	Guide / Top Menu	D. Menu
Input VCR/ DVR	Shift + 2	Guide / Top Menu	Shift + Menu
Input CBL/ SAT	Shift + 3	Guide / Top Menu	Guide
Input Game	Shift + 4	Prev CH / Menu	Menu
Input AUX	Shift + 5	Prev CH / Menu	Pre Ch
Input Tuner	Shift + 6	Up	Up
Input TV/ CD	Shift + 7	Left / Playlist/ Category	Left
Input Port	Shift + 8	Enter	Ok
Tone	Shift + Ok	Right / Playlist/ Category	Right
Tone +	Shift + Up	Down	Down
Tone -	Shift + Down	Setup	Options
Tun Mode	Smart	Audio	Dual
Muting	Mute	Return	Back
CH +	Ch +	I <<	I <<
CH -	Ch -	>>I	>>I

Original		Replacement	
	<<		<<
	Play	PLAY MODE	Play
	>>		>>
	Pause / Play Reverse		Pause
	Stop		Stop
MOVIE/TV SEARCH	Movie/TV / Searc	A	Red
MOVIE/TV SEARCH	Movie/TV / Searc	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat	B	Green
MUSIC REPEAT	Music / Repeat	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play	D	Blue
STEREO PLAY MODE	Stereo / Play	SHIFT + PLAY MODE	Shift + Play
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5

Original		Replacement	
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
+10 D.TUN DIMMER	+10 / Dimmer	SHIFT + GUIDE	Shift + Guide
+10 D.TUN DIMMER	D.Tun Tuner	APP MEDIA	Media
CLR SLEEP	Clear / Sleep	CLEAR EXIT	Exit
CLR SLEEP	Clear / Sleep	PROG SLEEP	Sleep

Original	Replacement	Original	Replacement
On/ Standby	Power	Display BD/ DVD	Info
Input BD/ DVD	SHIFT + 1 Shift + 1	Guide / Top Menu BD/ DVD	SHIFT + TOP MENU MENU Shift + Menu
Input VCR/ DVR	SHIFT + 2 Shift + 2	Guide / Top Menu BD/ DVD	E-MANUAL D.MENU D. Menu
Input CBL/ SAT	SHIFT + 3 Shift + 3	Guide / Top Menu BD/ DVD	GUIDE Guide
Input Game	SHIFT + 4 Shift + 4	Prev CH / Menu BD/ DVD	TOP MENU MENU Menu
Input AUX	SHIFT + 5 Shift + 5	Prev CH / Menu BD/ DVD	FAV PRE-CH Pre Ch
Input Tuner	SHIFT + 6 Shift + 6	Up BD/ DVD	Up
Input TV/ CD	SHIFT + 7 Shift + 7	Left / Playlist/ Category	Left
Input Port	SHIFT + 8 Shift + 8	Enter BD/ DVD	OK Ok
Tone	SHIFT + OK Shift + Ok	Right / Playlist/ Category	Right
Tone +	SHIFT + Shift + Up	Down BD/ DVD	Down
Tone -	SHIFT + Shift + Down	Setup BD/ DVD	SETTINGS OPT Options
Tun Mode	HOME SMART Smart	Audio BD/ DVD	SOUND DUAL Dual
Muting	MUTE Mute	Return BD/ DVD	RETURN BACK Back
Vol +	+ VOL Vol +	I << BD/ DVD	I <<
Vol -	VOL – Vol -	>>I BD/ DVD	>>I
On/ Standby	SHIFT + Shift + Power	<< BD/ DVD	<<

BD/ DVD

Original	Replacement	Original	Replacement
Play BD/ DVD	Play	7 BD/ DVD	7
>> BD/ DVD	>>	8 BD/ DVD	8
Pause BD/ DVD	Pause	9 BD/ DVD	9
Stop BD/ DVD	Stop	0 BD/ DVD	0
Movie/ TV / Searc BD/ DVD	Red	+10 / Dimmer	Shift + Guide
Movie/ TV / Searc BD/ DVD	TV/ R	CLR / Sleep	Exit
Music / Repeat BD/ DVD	Green	CLR / Sleep	Sleep
Music / Repeat BD/ DVD	Text		
Game / Random BD/ DVD	Yellow		
Stereo / Play Mode BD/ DVD	Blue		
Stereo / Play Mode BD/ DVD	Shift + Play		
1 BD/ DVD	1		
2 BD/ DVD	2		
3 BD/ DVD	3		
4 BD/ DVD	4		
5 BD/ DVD	5		
6 BD/ DVD	6		

Original	Replacement	Original	Replacement
On / Standby	Power	Display TV/CD	Info
Input BD/DVD	Shift + 1	Disc + / Album + TV/CD	Ch +
Input VCR/DVR	Shift + 2	Disc - / Album TV/CD	Ch -
Input CBL/SAT	Shift + 3	Up TV/CD	Up
Input Game	Shift + 4	Left / Playlist/Category	Left
Input Aux	Shift + 5	Enter TV/CD	Ok
Input Tuner	Shift + 6	Right / Playlist/Category	Right
Input TV/CD	Shift + 7	Down TV/CD	Down
Input Port	Shift + 8	Setup TV/CD	Options
Tone	Shift + Ok	Audio TV/CD	Dual
Tone +	Shift + Up	Return TV/CD	Back
Tone -	Shift + Down	I << TV/CD	I <<
Tun Mode	Smart	>>I TV/CD	>>I
Muting	Mute	<< TV/CD	<<
Vol +	Vol +	>> TV/CD	>>
Vol -	Vol -	Play TV/CD	Play
On / Standby	Shift + Power	Pause TV/CD	Pause

TV/CD

Original		Replacement	
■	Stop TV/CD	■	Stop
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	A	Red
MOVIE/TV SEARCH	Movie/TV / Search TV/CD	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat TV/CD	B	Green
MUSIC REPEAT	Music / Repeat TV/CD	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode TV/CD	D	Blue
STEREO PLAY MODE	Stereo / Play Mode TV/CD	SHIFT + PLAY MODE ▶	Shift + Play
1	1 TV/CD	1	1
2	2 TV/CD	2	2
3	3 TV/CD	3	3
4	4 TV/CD	4	4
5	5 TV/CD	5	5
6	6 TV/CD	6	6
7	7 TV/CD	7	7
8	8 TV/CD	8	8
9	9 TV/CD	9	9

Original		Replacement	
0	0 TV/CD	0	0
+10 D.TUN DIMMER	+10 / Dimmer	GUIDE	Guide
CLR SLEEP	CLR / Sleep TV/C	CLEAR EXIT	Exit
CLR SLEEP	CLR / Sleep TV/C	PROG SLEEP	Sleep

Original	Replacement
On / Standby	Power
Input BD/DVD	Shift + 1
Input VCR/DVR	Shift + 2
Input CBL/SAT	Shift + 3
Input Game	Shift + 4
Input AUX	Shift + 5
Input Tuner	Shift + 6
Input TV/CD	Shift + 7
Input Port	Shift + 8
Tone	Shift + Ok
Tone +	Shift + Up
Tone -	Shift + Down
Tun Mode	Smart
Muting	Mute
Vol +	Vol +
Vol -	Vol -
On / Standby Por	Shift + Power

Original	Replacement
Display Port	Info
CH + Port	Ch +
CH - Port	Ch -
Up Port	Up
Left / Playlist/Category	Left
Enter Port	Ok
Right / Playlist/Categor	Right
Down Port	Down
Setup Port	Options
Return Port	Back
I << Port	I <<
>>I Port	>>I
<< Port	<<
Play Port	Play
>> Port	>>
Pause / Play Reverse Port	Pause
Stop Port	Stop

Original		Replacement	
MOVIE/TV SEARCH	Movie/TV / Searc Port	A	Red
MOVIE/TV SEARCH	Movie/TV / Searc Port	SEARCH TV/R	TV/R
MUSIC REPEAT	Music / Repeat	B	Green
MUSIC REPEAT	Music / Repeat	REPEAT TEXT	Text
GAME RANDOM	Game / Random	C	Yellow
STEREO PLAY MODE	Stereo / Play Mode Port	D	Blue
STEREO PLAY MODE	Stereo / Play Mode Port	SHIFT + PLAY MODE ▶	Shift + Play
1	1 Port	1	1
2	2 Port	2	2
3	3 Port	3	3
4	4 Port	4	4
5	5 Port	5	5
6	6 Port	6	6
7	7 Port	7	7
8	8 Port	8	8
9	9 Port	9	9
0	0 Port	0	0

Original		Replacement	
+10 D.TUN DIMMER	+10 / Dimmer	GUIDE	Guide
CLR SLEEP	CLR / Sleep Port	CLEAR EXIT	Exit
CLR SLEEP	CLR / Sleep Port	PROG SLEEP	Sleep