Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ON	On		Power
STANDBY	Standby	SHIFT +	Shift + Power
RETURN	Return	RETURN BACK	Back / Return
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
CH DISC	CH+/Disc+	CH PAGE +	CH+ / Page+
ENTER	Enter	OK	OK
	Up		Up
VOL	Vol +	VOL +	Vol +
CH DISC	CH-/Disc-	CH PAGE −	CH- / Page-
	Left		Left
	Right		Right
VOL	Vol -	VOL −	Vol -
	Down		Down
AUDIO SEL TV/VCR	Audio Sel	LANG I/II AUDIO	Audio / Lang I/II
CH SEL TOP MENU	CH Sel	TOP MENU D.MENU	D.Menu / Top
TEST MENU	Test / Menu	HOME MENU	Menu / Home

Original		Replacement	
MUTING M	Muting	DIMMER MUTE	Mute / Dimmer
ANGLE LEVEL	Level Down	SHIFT +	Shift + Down
SUBTITLE LEVEL	Level Up	SHIFT +	Shift + Up
	I<<	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Stop	HOLD	Stop / Hold
	>>	TUNE+	>> / Tune+
RANDOM REC	Rec / Random	Prime Video RANDOM	Blue / Prime Video / Random
	Play Rev.	STEP-FREEZE	Pause / Step / Freeze
REPEAT	Open / Close	SURROUND	Eject / Surround
DVD	Input Sel. DVD	SHIFT + DVD 2	Shift + 2
CD	Input Sel. CD	SHIFT + CD-STB 3	Shift + 3
ALBUM V1	Input Sel. V1	SHIFT + TV 1	Shift + 1
ARTIST V2	Input Sel. V2	SHIFT + VIDEO 4	Shift + 4
GENRE TAP	Input Sel. TAP	SHIFT + TAPE 5	Shift + 5

Original		Replacement		Original		Replacement	
PLAYLIST TUN	Input Sel. TUN	SHIFT + TUNER 6	Shift + 6	9 WXYZ Re-EQ	Re-EQ	EQ SUBTITLE	Subtitle / EQ
V3	Input Sel. V3	SHIFT + AUX-HDD 7	Shift + 7	+10 CAPS DISPLAY	Display	MEDIA DISPLAY	Display / Media
V4	Input Sel. V4	SHIFT + USB 8	Shift + 8	0 DIMMER	Dimmer	SHIFT + DIMMER MUTE	Shift + Mute / Dimmer
V5	Input Sel. V5	SHIFT + BLUETOOTH 9	Shift + 9	0 DIMMER	Dimmer	HDMI-SAT 0	0
PH	Input Sel. PH	SHIFT + HDMI-SAT 0	Shift + 0	SEARCH DEL ZONE 2 ENTER	Zone 2	LIST SMART	Smart / List
1 @.-'/ PURE A	Pure A	TV 1	1				
2 ABC DIRECT	Direct	DVD 2	2				
3 DEF STEREO	Stereo	CD-STB 3	3				
4 GHI SURR	Surr.	VIDEO 4	4				
4 GHI SURR	Surr.	SHIFT + SURROUND ⏏	Shift + Eject / Surround				
5 JKL THX	THX	TAPE 5	5				
6 MNO ALL ST	All St.	TUNER 6	6				
7 PQRS ◄ DSP	◄ DSP	AUX-HDD 7	7				
7 PQRS ◄ DSP	◄ DSP	SHIFT + ◄	Shift + Left				
8 TUV DSP ►	DSP ►	USB 8	8				
8 TUV DSP ►	DSP ►	SHIFT + ►	Shift + Right				
9 WXYZ Re-EQ	Re-EQ	BLUETOOTH 9	9				

Original	Replacement
Sleep	Sleep / Timer
On	Power
Standby	Shift + Power
Return	Back / Return
Setup	Setup / OPT /
Disc+	CH+ / Page+
Vol +	Vol +
Disc-	CH- / Page-
Vol -	Vol -
Audio Sel /	Audio / Lang I/II
CH Sel / Top Menu	D. Menu / Top
Test / Menu	Menu / Home
Muting	Mute / Dimmer
Angle	Info / Angle
Subtitle	Subtitle / EQ
I <<	I << / Preset-
Play	Play / Slow

Original	Replacement
>>I	>>I / Preset+
<<	<< / Tune-
Stop	Stop / Hold
>>	>> / Tune+
Random	Blue / Prime Video / Random
Pause	Pause / Step / Freeze
Eject	Eject / Surround
Input Sel. DVD	Shift + 2
Input Sel. CD	Shift + 3
Input Sel. V1	Shift + 1
Input Sel. V2	Shift + 4
Input Sel. TAP	Shift + 5
Input Sel. TUN	Shift + 6
Input Sel. V3	Shift + 7
Input Sel. V4	Shift + 8
Input Sel. V5	Shift + 9
Input Sel. PH	Shift + 0

Original		Replacement		Original	Replacement
1 @.-'/ PURE A	1	TV 1	1		
2 ABC DIRECT	2	DVD 2	2		
3 DEF STEREO	3	CD - STB 3	3		
4 GHI SURR	4	VIDEO 4	4		
5 JKL THX	5	TAPE 5	5		
6 MNO ALL ST	6	TUNER 6	6		
7 PQRS ◄ DSP	7	AUX - HDD 7	7		
8 TUV DSP ►	8	USB 8	8		
9 WXYZ Re-EQ	9	BLUETOOTH 9	9		
+10 CAPS DISPLAY	+10 / --/---	-/-- GUIDE EPG	Guide / EPG / -/--		
0 DIMMER	0	HDMI - SAT 0	0		
SEARCH DEL ZONE 2 ENTER	Search/Enter	NETFLIX SEARCH	Red / Netflix / Search		
SEARCH DEL ZONE 2 ENTER	Search/Enter	PC FAV MARKER	Fav / Marker / PC		

Original		Replacement		Original		Replacement	
ON	On		Power	2 ABC DIRECT	2	DVD 2	2
STANDBY	Standby	SHIFT +	Shift + Power	3 DEF STEREO	3	CD-STB 3	3
CH DISC +	Disc+	CH PAGE +	CH+ / Page+	4 GHI SURR	4	VIDEO 4	4
VOL +	Vol +	VOL +	Vol +	5 JKL THX	5	TAPE 5	5
VOL -	Vol -	VOL -	Vol -	6 MNO ALL ST	6	TUNER 6	6
MUTING	Muting	DIMMER MUTE	Mute / Dimmer	7 PQRS DSP	7	AUX-HDD 7	7
SUBTITLE LEVEL	Subtitle	EQ SUBTITLE	Subtitle / EQ	8 TUV DSP	8	USB 8	8
	I<<	PRESET-	I<< / Preset-	9 WXYZ Re-EQ	9	BLUETOOTH 9	9
	Play	SLOW	Play / Slow	+10 CAPS DISPLAY	+10	-/-- GUIDE EPG	Guide / EPG / -/--
	>>I	PRESET+	>>I / Preset+	0 DIMMER	0	HDMI-SAT 0	0
	<<	TUNE-	<< / Tune-				
	Stop	HOLD	Stop / Hold				
	>>	TUNE+	>> / Tune+				
RANDOM RANDOM REC	Random	Prime Video RANDOM	Blue / Prime Video / Random				
	Pause	STEP-FREEZE	Pause / Step / Freeze				
REPEAT	Eject	SURROUND	Eject / Surround				
1 @.-/ PURE A	1	TV 1	1				

Original		Replacement	
SLEEP	Sleep	TIMER SLEEP	Sleep / Timer
ON	On		Power
STANDBY	Standby	SHIFT +	Shift + Power
	NET A	LIST SMART	Smart / List
SETUP	Setup	OPT-TOOLS SETUP	Setup / OPT /
CH DISC +	CH+ / Disc+	CH PAGE +	CH+ / Page+
ENTER	Enter	OK	OK
	Up		Up
VOL +	Vol +	VOL +	Vol +
CH DISC -	CH- / Disc-	CH PAGE -	CH- / Page-
	Left		Left
	Right		Right
VOL -	Vol -	VOL -	Vol -
	Down		Down
MUTING	Muting	DIMMER MUTE	Mute / Dimmer
	I<<	PRESET-	I<< / Preset-
	Play	SLOW	Play / Slow

Original		Replacement	
	>>I	PRESET+	>>I / Preset+
	<<	TUNE-	<< / Tune-
	Stop	HOLD	Stop / Hold
	>>	TUNE+	>> / Tune+
RANDOM REC	Rec / Random	SHIFT +	Shift + Blue / Prime
RANDOM REC	Rec / Random	REC MODE	Rec / Rec Mode
	Pause / Play Rev	STEP-FREEZE	Pause / Step / Freeze
REPEAT	Eject / Repeat	SHIFT +	Shift + Green / APP /
REPEAT	Eject / Repeat	SURROUND	Eject / Surround
ALBUM V1	Album	NETFLIX SEARCH	Red / Netflix / Search
ARTIST V2	Artist	APP REPEAT	Green / APP / Repeat
GENRE TAP	Genere	YouTube REPEAT A-B	Yellow / YouTube / Repeat
PLAYLIST TUN	Playlist	Prime Video RANDOM	Blue / Prime Video / Random
1 @.-'/ PURE A	1 / Symbols	TV 1	1
2 ABC DIRECT	2 / ABC	DVD 2	2
3 DEF STEREO	3 / DEF	CD-STB 3	3
4 GHI SURR	4 / GHI	VIDEO 4	4

Original		Replacement		Original	Replacement
5 JKL THX	5 / JKL	TAPE 5	5		
6 MNO ALL ST	6 / MNO	TUNER 6	6		
7 PQRS ◄ DSP	7 / PQRS	AUX - HDD 7	7		
8 TUV DSP ►	8 / TUV	USB 8	8		
9 WXYZ Re-EQ	9 / WXYZ	BLUETOOTH 9	9		
+10 CAPS DISPLAY	Display	MEDIA DISPLAY	Display / Media		
+10 CAPS DISPLAY	+10 / CAPS	-/-- GUIDE EPG	Guide / EPG / -/--		
0 DIMMER	0 / Space	HDMI - SAT 0	0		
SEARCH DEL ZONE 2 ENTER	Search / Del	PC FAV MARKER	Fav / Marker / PC		
SEARCH DEL ZONE 2 ENTER	Search / Del	SHIFT + NETFLIX SEARCH	Shift + Red / Netflix /		