Mandis shop

R- 40A01

Original	Replacement
Power	Power
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8
9	9
Source/[≡]	AV / Input / RDS
0	0
Normal/OK/[≡i]	OK
PR+	CH+ / Page+
Up	Up
Vol -	Vol -
Left/[≡+]	Left

Original	Replacement
Menu	Menu / Home
Right/[≡o]	Right
Vol +	Vol +
Down	Down
PR-	CH- / Page-
Sleep/[≡♦]	Sleep / Timer
Mute	Mute / Dimmer
Recall/[≡?]	Back / Return
Red/Skip	Red / Netflix / Search
Green/Movie	Green / APP / Repeat
[≡x]	Exit / Cancel / Clear
Yellow/Delete	Yellow / YouTube / Repeat
Blue/Mode	Blue / Prime Video / Random
[≡]	Text / Goto

https://al-remotecontrols.nl/en/1610-379-replacement-remote-control-for-R40A5-B7-R40A01.htm