Original		Replacement	
I/⏻	Power	⏻	Power
THEATRE SYNC	Power Theatre	SHIFT + ⏻	Shift + Power
MENU	Menu	TOP MENU / MENU	Menu
TOP MENU	Top Menu	SHIFT + TOP MENU / MENU	Shift + Menu
RETURN	Return	RETURN / BACK	Back
MUTING	Muting	MUTE	Mute
VOLUME +	Volume+	+ VOL	Vol +
VOLUME –	Volume-	VOL –	Vol -
▲	Up	▲	Up
ENTER	Enter	OK	Ok
▼	Down	▼	Down
▶	Right	▶	Right
◀	Left	◀	Left
▷	Play	PLAY MODE / ▶	Play
❚❚	Pause	❚❚	Pause
■	Stop	■	Stop
TUNING – SLOW ◀◀	<<| / ◁ / Tuning- Slow	«	<<

Original		Replacement	
TUNING + SLOW ▶▶	I>/ >>/ Tuning+	»	>>
PRESET – ⏮	I<<| / Preset-	⏮	I<<
PRESET + ⏭	>>I / Preset+	⏭	>>I
DISPLAY	[*] Display	DISPLAY / INFO	Info
REPLAY ←	← / Replay/ ◁ I Step	CH –	Ch -
ADVANCE →	Step I>/ Advance/ · →	+ CH	Ch +
CLEAR	Clear	CLEAR / EXIT	Exit
DISC SKIP	Disc Skip	FAV / PRE-CH	Pre Ch
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9

Original		Replacement	
0	0	0	0
ANGLE	Angle	A	Red
SUBTITLE D.TUNING	Subtitle/D.Tuning	AD SUBT	Subt
AUDIO	Audio	SOUND DUAL	Dual
DYNAMIC BASS	Dynamic Bass	D	Blue
MOVIE/ MUSIC	Movie/Music	C	Yellow
SOUND FIELD	Sound Field	B	Green
PROGRESSIVE	Progressive	SETTINGS OPT	Options
FUNCTION	Function	SEARCH TV/R	TV/R
DISPLAY	Display	SHIFT +	DISPLAY INFO Shift + Info
AMP MENU	AMP Menu	APP MEDIA	Media
SLEEP	Sleep	PROG SLEEP	Sleep
PICTURE NAVI	Picture Navi	-/-- GUIDE	Guide

Original	Replacement

Original		Replacement		Original	Replacement
TV I/⏻	Power	⏻	Power		
1	1	1	1		
2	2	2	2		
3	3	3	3		
4	4	4	4		
5	5	5	5		
6	6	6	6		
7	7	7	7		
8	8	8	8		
9	9	9	9		
0	0	0	0		
-/-- CLEAR	- / - -	-/-- GUIDE	Gui de		
TV VOL +	TV Vol +	+ VOL	Vol +		
–	TV Vol -	VOL –	Vol -		
TV CH +	TV CH+	+ CH	Ch +		
–	TV CH-	CH –	Ch -		
TV/VIDEO	Tv/ Vi deo	SEARCH TV/R	TV/ R		