Mandis shop

Denon RC-896-CD-AUDIO TV)

Original	Replacement
AVR/AVC On	Power
Power Tv	Yellow / YouTube / Repeat
Power VCR	Green / APP / Repeat
Power DVD/VDP	Red / Netflix / Search
AVR/AVC Off	Shift + Power
1	1
2 / CD	2
3 / DVD/VDP	3
4 / V.AUX	4
5 / VCR	5
6	6
7 / TV/DBS	7
8 / Input Mode	8
9 / CDR/TAPE	9
0 / Tuner	0
Shift	Info / Angle
Surround Mode	Eject / Surround

Original	Replacement
<< TAPE-VCR	Shift + << /
TAPE-VCR >>	Shift + >> /
Channel +	CH+ / Page+
TAPE-VCR Pause/Rev. Play	Shift + Pause / Step /
Stop TAPE-VCR	Shift + Stop /
TAPE-VCR Play	Shift + Play /
Channel -	CH- / Page-
Play CD/MD/CDR-DVD/	Play / Slow
Disc Skip+	AV / Input / RDS
I << CD/MD/CDR-DVD/	I << / Preset-
Pause CD/MD/CDR-DVD/	Pause / Step / Freeze
CD/MD/CDR-DVD/ VDP >>I	>>I / Preset+
<< CD/MD/CDR-DVD/	<< / Tune-
Stop CD/MD/CDR-DVD/	Stop / Hold
CD/MD/CDR-DVD/ VDP >>	>> / Tune+
System/Setup	D.Menu / Top
Up	Up

Original		Replacement		Original		Replacement	
SURROUND MENU	Surround/Menu	HOME MENU	Menu / Home				
MASTER VOL ▲	Master Volume	VOL +	Vol +				
◄	Left	◄	Left				
CH SELECT SELECT	CH. Select/Select	LIST SMART	Smart / List				
►	Right	►	Right				
MASTER VOL ▼	Master Volum	VOL −	Vol -				
T.TONE RETURN	T. Tone/Return	RETURN BACK	Back / Return				
▼	Down	▼	Down				
STATUS DISPLAY	Status/Display	MEDIA DISPLAY	Display / Media				
MUTING	Muting	DIMMER MUTE	Mute / Dimmer				
CHANN −	Tv Channel -	SHIFT + CH PAGE −	Shift + CH- /				
NNEL +	Tv Channel +	SHIFT + CH PAGE +	Shift + CH+ /				
VOLU	Tv Volume-	SHIFT + VOL −	Shift + Vol -				
LUME ▲	Tv Volume+	SHIFT + VOL +	Shift + Vol +				

Original	Replacement	Original	Replacement
AVR/AVC On	Power		
AVR/AVC Off	Shift + Power		
Play CD/MD/CDR-DVD/	Play / Slow		
I<< CD/MD/CDR-DVD/	I<< / Preset-		
Pause CD/MD/CDR-DVD/	Pause / Step / Freeze		
CD/MD/CDR-DVD/ VDP >>I	>>I / Preset+		
<< CD/MD/CDR-DVD/	<< / Tune-		
Stop CD/MD/CDR-DVD/	Stop / Hold		
CD/MD/CDR-DVD/ VDP >>	>> / Tune+		

Original		Replacement	
AVR/AVC On		Power	
AVR/AVC Off		Shift +	Power
<< TAPE-VCR		<< / Tune-	
TAPE-VCR >>		>> / Tune+	
Channel +		CH+ / Page+	
Pause	CD/MD/CDR-DVD/	Pause / Step /	Freeze
Channel -		CH- / Page-	
Stop TAPE-VCR		Shift +	Stop /
TAPE-VCR >		Shift +	Play /
Title	CD/MD/CDR-DVD/	Sound / Title	
Play	CD/MD/CDR-DVD/	Play / Slow	
Disc Skip+	CD/MD/CDR-DVD/	Blue / Prime Video /	Random
I<<	CD/MD/CDR-DVD/	I<< / Preset-	
	CD/MD/CDR-DVD/ VDP >>I	>>I / Preset+	
Stop	CD/MD/CDR-DVD/	Stop / Hold	
System/Setup		D.Menu / Top	
Up		Up	

Original		Replacement	
Surround/Menu		Menu / Home	
Left		Left	
CH.Select/Select		Smart / List	
Right		Right	
T.Tone/Return		Back / Return	
Down		Down	
Status/Display		Display / Media	