Mandis shop

Sony RM-SED1

Original	Replacement
Power	Power
Display	Info
DBFB	Smart
Play CD	Play
Pause CD	Pause
Stop CD	Stop
Play	Red
I<<</- Tuner/band	I<<
>>I/+	>>I
<> Tape	Green
<< Tape	<<
>> Tape	>>
Rec	Rec
Dolby NR	Dual
Dir Mode	Media
CD Repeat	Text
Stereo/Mono	Options

Original	Replacement
Tuning / Play	Blue
Tuning / Play	Shift + Play
Vol +	Vol +
Vol -	Vol -
Enter/On/Off	Ok
Up/Memory	Up
Right/Timer	Right
Left/Timer Set	Left
Down/Sleep	Down

https://al-remotecontrols.nl/en/Sony/1638232-replacement-remote-control-for-Sony-RM-SED1-97681.htm