| Original | Replacement | Original | Replacement |
|---|---|---|---|
| [ ]→ | Exit / Cancel / Clear | [≡] | Text / Goto |
| Power | Power | Left | Left |
| [1\|2] | Shift + Red / Netflix / | OK | OK |
| [↤\|↦] | Shift + Green / APP / | Right | Right |
| [ \| ⏭\|⏮ ] | Shift + Yellow / YouTube / | [⏭\|⏮] | Pause / Step / Freeze |
| Red / Rec | Rec / Rec Mode | Down | Down |
| Red / Rec | Red / Netflix / Search | [...] | Subtitle / EQ |
| Green / << | Green / APP / Repeat | Vol + | Vol + |
| Green / << | <<  / Tune- | Mute | Mute / Dimmer |
| Yellow / Stop | Stop / Hold | P+ | CH+ / Page+ |
| Yellow / Stop | Yellow / YouTube / Repeat | Vol - | Vol - |
| Blue / Play | Blue / Prime Video / Random | P- | CH- / Page- |
| Blue / Play | Play / Slow | 1 | 1 |
| White / >> | >> / Tune+ | 2 | 2 |
| White / >> | Fav / Marker / PC | 3 | 3 |
| [ \| ] | Shift + Guide / EPG / -/-- | 4 | 4 |
| Up | Up | 5 | 5 |

| Original | | Replacement | | Original | | Replacement | |
|---|---|---|---|---|---|---|---|
| 6 | 6 | TUNER 6 | 6 | | | | |
| 7 | 7 | AUX - HDD 7 | 7 | | | | |
| 8 | 8 | USB 8 | 8 | | | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | | | |
| [i+] | | ANGLE INFO | Info / Angle | | | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | | | |
| P<P | P<P / -/-- | -/-- GUIDE EPG | Guide / EPG / -/-- | | | | |
| [⏲] | | TIMER SLEEP | Sleep / Timer | | | | |
| [?] | | RDS AV INPUT | AV / Input / RDS | | | | |
| ZOOM | [↕] / Zoom | SIZE ZOOM | Zoom / Size | | | | |
| SMART SOUND | Smart Sound | TITLE SOUND | Sound / Title | | | | |
| [\|<>\|] | | TOP MENU D.MENU | D.Menu / Top | | | | |
| SMART PICTURE | Smart Picture | FORMAT PICTURE | Picture / Format | | | | |
| INSTANT | Instant Rec | SHIFT + REC MODE | Shift + Rec / Rec Mode | | | | |
| I-II | I-II | LANG I/II AUDIO | Audio / Lang I/II | | | | |
| DNR | DNR | RETURN BACK | Back / Return | | | | |
| [▟] | | OPT-TOOLS SETUP | Setup / OPT / Tools | | | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| DVD | SHIFT + DVD 2 — Shift + 2 | Vol + | VOL + — Vol + |
| [ 1\| 2] | NETFLIX SEARCH — Red / Netflix / Search | Mute | DIMMER MUTE — Mute / Dimmer |
| [ ↤\| →] | APP REPEAT — Green / APP / Repeat | P+ | CH PAGE + — CH+ / Page+ |
| [ \| ⏭ < ] | YouTube REPEAT A-B — Yellow / YouTube / Repeat | Vol - | VOL − — Vol - |
| << | TUNE- ◀◀ — << / Tune- | P- | CH PAGE − — CH- / Page- |
| Stop | HOLD ■ — Stop / Hold | 1 | TV 1 — 1 |
| Play | SLOW ▶ — Play / Slow | 2 | DVD 2 — 2 |
| >> | TUNE+ ▶▶ — >> / Tune+ | 3 | CD-STB 3 — 3 |
| [ \| ] | SHIFT + GUIDE EPG — Shift + Guide / EPG / -/-- | 4 | VIDEO 4 — 4 |
| Up | ▲ — Up | 5 | TAPE 5 — 5 |
| [ ≡] | GOTO TEXT — Text / Goto | 6 | TUNER 6 — 6 |
| Left | ◀ — Left | 7 | AUX-HDD 7 — 7 |
| OK | OK — OK | 8 | USB 8 — 8 |
| Right | ▶ — Right | 9 | BLUETOOTH 9 — 9 |
| [ ⏭ <] | STEP-FREEZE ⏸ — Pause / Step / Freeze | [ i +] | ANGLE INFO — Info / Angle |
| Down | ▼ — Down | 0 | HDMI-SAT 0 — 0 |
| [ . . . ] | EQ SUBTITLE — Subtitle / EQ | P<P / -/-- | -/-- GUIDE EPG — Guide / EPG / -/-- |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| Smart Sound | Sound / Title | | |
| [\|<>\|] | D.Menu / Top | | |
| Smart Picture | Picture / Format | | |
| Instant Rec | Rec / Rec Mode | | |
| [ ] | Setup / OPT / | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| [ ]→ | Exit / Cancel / Clear | [≡] | Text / Goto |
| Power | Power | Left | Left |
| [1\|2] | Shift + Red / Netflix / | OK | OK |
| [↤\|↦] | Shift + Green / APP / | Right | Right |
| [ \| ⏭\|⏮ ] | Shift + Yellow / YouTube / | [⏭\|⏮] | Pause / Step / Freeze |
| Red / Rec | Red / Netflix / Search | Down | Down |
| Red / Rec | Rec / Rec Mode | [...] | Subtitle / EQ |
| Green / << | Green / APP / Repeat | Vol + | Vol + |
| Green / << | <<  / Tune- | Mute | Mute / Dimmer |
| Yellow / Stop | Stop / Hold | P+ | CH+ / Page+ |
| Yellow / Stop | Yellow / YouTube / Repeat | Vol - | Vol - |
| Blue / Play | Blue / Prime Video / Random | P- | CH- / Page- |
| Blue / Play | Play / Slow | 1 | 1 |
| White / >> | Fav / Marker / PC | 2 | 2 |
| White / >> | >> / Tune+ | 3 | 3 |
| [ \| ] | Shift + Guide / EPG / -/-- | 4 | 4 |
| Up | Up | 5 | 5 |

| Original | | Replacement | | Original | |
|---|---|---|---|---|---|
| 6 | 6 | TUNER 6 | 6 | | |
| 7 | 7 | AUX - HDD 7 | 7 | | |
| 8 | 8 | USB 8 | 8 | | |
| 9 | 9 | BLUETOOTH 9 | 9 | | |
| [i+] | | ANGLE INFO | Info / Angle | | |
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| P<P | P<P / -/-- | -/-- GUIDE EPG | Guide / EPG / -/-- | | |
| [⏲] | | TIMER SLEEP | Sleep / Timer | | |
| [?] | | RDS AV INPUT | AV / Input / RDS | | |
| [↕] | [↕] / Zoom | SIZE ZOOM | Zoom / Size | | |
| Smart Sound | Smart Sound | TITLE SOUND | Sound / Title | | |
| [\|<>\|] | | TOP MENU D.MENU | D.Menu / Top | | |
| Smart Picture | Smart Picture | FORMAT PICTURE | Picture / Format | | |
| Instant Rec | Instant Rec | SHIFT + REC MODE | Shift + Rec / Rec Mode | | |
| I-II | I-II | LANG I/II AUDIO | Audio / Lang I/II | | |
| DNR | DNR | RETURN BACK | Back / Return | | |
| [▟] | | OPT-TOOLS SETUP | Setup / OPT / Tools | | |

| Original | Replacement | Original | Replacement |
|---|---|---|---|
| [ ]→ | Exit / Cancel / Clear | Down | Down |
| Power | Power | [...] | Subtitle / EQ |
| [1\|2] | Red / Netflix / Search | Vol + | Vol + |
| [↤\|↦] | Green / APP / Repeat | Mute | Mute / Dimmer |
| [ \| ⏭\|⏮ ] | Yellow / YouTube / Repeat | P+ | CH+ / Page+ |
| Rec | Rec / Rec Mode | Vol - | Vol - |
| << | << / Tune- | P- | CH- / Page- |
| Stop | Stop / Hold | 1 | 1 |
| Play | Play / Slow | 2 | 2 |
| >> | >> / Tune+ | 3 | 3 |
| [ \| ] | Shift + Guide / EPG / -/-- | 4 | 4 |
| Up | Up | 5 | 5 |
| [≡] | Text / Goto | 6 | 6 |
| Left | Left | 7 | 7 |
| OK | OK | 8 | 8 |
| Right | Right | 9 | 9 |
| [⏭\|⏮] | Pause / Step / Freeze | [i+] | Info / Angle |

| Original | | Replacement | | Original | Replacement |
|---|---|---|---|---|---|
| 0 | 0 | HDMI - SAT 0 | 0 | | |
| P<P / -/-- | P<P / -/-- | -/-- GUIDE EPG | Guide / EPG / -/-- | | |
| [◷] | [◷] | TIMER SLEEP | Sleep / Timer | | |
| [?] | [?] | RDS AV INPUT | AV / Input / RDS | | |
| [↕] / Zoom | [↕] / Zoom | SIZE ZOOM | Zoom / Size | | |
| Smart Sound | Smart Sound | TITLE SOUND | Sound / Title | | |
| [\|<>\|] | [\|<>\|] | TOP MENU D.MENU | D.Menu / Top | | |
| Smart Picture | Smart Picture | FORMAT PICTURE | Picture / Format | | |
| Instant Rec | Instant Rec | SHIFT + REC MODE | Shift + Rec / Rec Mode | | |
| I-II | I-II | LANG I/II AUDIO | Audio / Lang I/II | | |
| DNR | DNR | RETURN BACK | Back / Return | | |
| [▟] | [▟] | OPT-TOOLS SETUP | Setup / OPT / | | |