Original		Replacement	
POWER	Power		Power
SOURCE	Source	TIMER AV	AV
HDMI	HDMI	SEARCH TV/R	TV/R
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0	0	0	0
TTX/MIX	TTX/MIX	REPEAT TEXT	Text
PRE-CH	PRE-CH	FAV PRE-CH	Pre Ch
	Vol +	VOL +	Vol +
	Vol -	VOL −	Vol -

Original		Replacement	
CH LIST	CH. List	DISC NAV LIST	List
P	P+	+ CH	Ch +
P	P-	CH −	Ch -
MUTE	Mute	MUTE	Mute
CONTENT	Content	E-MANUAL D.MENU	D. Menu
MENU	Menu	TOP MENU MENU	Menu
GUIDE	Guide	-/-- GUIDE	Guide
TOOLS	Tools	SETTINGS OPT	Options
CLOCK INFO	Info/Clock	DISPLAY INFO	Info
RETURN	Return	RETURN BACK	Back
EXIT	Exit	CLEAR EXIT	Exit
	Up		Up
	Down		Down
	Right		Right
	Left		Left
	Enter	OK	Ok
A	Red	A	Red

Original		Replacement		Original	Replacement
B	Green	B	Green		
C	Yellow	C	Yellow		
D	Blue	D	Blue		
HOME	Home	HOME SMART	Smart		
3D	3D	ECO 3D	3D		
DUAL-HI	Dual I-II	SOUND DUAL	Dual		
ALARM	Alarm	APP MEDIA	Media		
P.SIZE	P. Size	PICTURE FORMAT	Format		
SUBT.	Subt.	AD SUBT	Subt		
<<	<<	<<	<<		
I<<	I<<	I<<	I<<		
Pause	Pause	Pause	Pause		
>>I	>>I	>>I	>>I		
>>	>>	>>	>>		
Rec	Rec	REC MODE	Rec		
Play	Play	PLAY MODE	Play		
Stop	Stop	Stop	Stop		