Original		Replacement	
1	1	1	1
AUX	AUX	TIMER AV	AV
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7/P	7/P	7	7
8	8	8	8
9	9	9	9
0	0	0	0
10 RETURN	10/Return	SHIFT + GUIDE	Shift + Guide
+10	+10/+100	FAV PRE-CH	Pre Ch
TA/NEWS/INFO	Play/TA/News/Inf	PLAY MODE ▶	Play
PTY SEARCH	Pause/PTY Search	❚❚	Pause
DISPLAY MODE	Stop/Display	■	Stop
PTY+ FF	>>I / PTY+	>>I	>>I

Original		Replacement	
PTY- REW	I<<I / PTY-	I<<	I<<
FM/AM	FM/AM	HOME SMART	Smart
FM MODE	FM Mode	APP MEDIA	Media
PTY SEARCH	Pause FM/AM	OK	Ok
TA/NEWS/INFO	Play FM/AM	▲	Up
DISPLAY MODE	Stop FM/AM	▼	Down
PTY+ FF	>>I FM/AM	▶	Right
PTY- REW	I<<I FM/AM	◀	Left
TEST	Test	SETTINGS OPT	Options
EFFECT	Effect	SOUND DUAL	Dual
SURR L	Level - SURR L	VOL −	Vol -
SURR L	Level + SURR L	+ VOL	Vol +
1	1 FM/AM	SHIFT + 1	Shift + 1
2	2 FM/AM	SHIFT + 2	Shift + 2
3	3 FM/AM	SHIFT + 3	Shift + 3
4	4 FM/AM	SHIFT + 4	Shift + 4
5	5 FM/AM	SHIFT + 5	Shift + 5

Original	Replacement	Original	Replacement
6 FM/AM	SHIFT + 6 Shift + 6		
7 FM/AM	SHIFT + 7 Shift + 7		
8 FM/AM	SHIFT + 8 Shift + 8		
9 FM/AM	SHIFT + 9 Shift + 9		
10 FM/AM	GUIDE Guide		
+10 FM/AM	SHIFT + PRE-CH Shift + Pre Ch		
SURR R Level + SURR R	CH + Ch +		
SURR R Level - SURR R	CH − Ch -		
CENTER Level + Center	>>		
CENTER Level - Center	<<		
SUBWFR Level + SUBWFR	SEARCH TV/R TV/R		
SUBWFR Level - SUBWFR	ECO 3D 3D		
FRONT L Level + Front L	B Green		
FRONT L Level - Front L	A Red		
FRONT R Level + Front R	D Blue		
FRONT R Level - Front R	C Yellow		

Original		Replacement	
	Up		Up
	Down		Down
	Right		Right
	Left		Left
ENTER	Enter	OK	Ok
MENU	Menu	TOP MENU MENU	Menu
PTY SEARCH	Pause/PTY Search		Pause
TA/NEWS/INFO	Play/TA/News/Inf	PLAY MODE	Play
DISPLAY MODE	Stop/Display		Stop
PTY REW	I<<</PTY-		I<<
PTY FF	>>I/PTY+		>>I
TA/NEWS/INFO	Play VCR	2	2
PTY SEARCH	Pause VCR	5	5
DISPLAY MODE	Stop VCR	8	8
PTY FF	>>I VCR	6	6
PTY REW	I<< VCR	4	4
REC PAUSE	Rec Pause VCR	REC MODE	Rec

Original	Replacement

Original		Replacement	
AUDIO	Audio Standby		Power
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7/P	7/P	7	7
TV CH +	Tv CH+	CH +	Ch +
TV CH −	Tv CH-	CH −	Ch -
VCR CH +	VCR CH+	SHIFT + CH +	Shift + Ch +
VCR CH −	VCR CH-	SHIFT + CH −	Shift + Ch -
TV	TV Standby	A	Red
VCR	VCR Standby	B	Green
DVD	DVD Standby	C	Yellow
TA/NEWS/INFO	Play/TA/News/Inf	PLAY MODE	Play
PTY SEARCH	Pause/PTY Search		Pause

Original		Replacement	
DISPLAY MODE	Stop/Display		Stop
SLEEP	Sleep	PROG SLEEP	Sleep
PTY+ FF	>>I / PTY+		>>I
PTY- REW	I<< / PTY-		I<<
TV/VIDEO	Tv/Video	SEARCH TV/R	TV/R
ANALOG/ DIGITAL	Analog/Digital	APP MEDIA	Media
DIMMER	Dimmer	ECO 3D	3D
SURROUND	Surround	SOUND DUAL	Dual
DSP	DSP	TIMER AV	AV
SURROUND/ DSP OFF	Surround DSP	AD SUBT	Subt
+	Vol +	+ VOL	Vol +
− VOLUME	Vol -	VOL −	Vol -
TV VOLUME +	Tv Vol +		Right
TV VOLUME −	Tv Vol -		Left
MUTING	Muting	MUTE	Mute
VCR	VCR	RETURN BACK	Back
FM/AM	FM/AM	SETTINGS OPT	Options

Original	Replacement	Original	Replacement
FM MODE FM/ Mode	REPEAT TEXT Text		

Original		Replacement	
REC PAUSE	Rec Pause	REC MODE	Rec
PTY SEARCH	Pause		Pause
DISPLAY MODE	Stop		Stop
TA/NEWS/INFO	Play	PLAY MODE	Play
PTY FF	>>I		>>I
PTY REW	I <<		I <<
TV SOUND	TV Sound	HOME SMART	Smart
1	1 TV Sound	1	1
2	2 TV Sound	2	2
3	3 TV Sound	3	3
4	4 TV Sound	4	4
5	5 TV Sound	5	5
6	6 TV Sound	6	6
7/P	7 TV Sound	7	7
8	8 TV Sound	8	8
9	9 TV Sound	9	9
0	0 TV Sound	0	0

Original		Replacement	
10 RETURN	10 TV Sound	GUIDE	Guide
+10	+10 TV Sound	FAV PRE-CH	Pre Ch