Original	Replacement	Original	Replacement
Power	Power	Menu	Menu
1	1	Exit	Exit
2	2	Back	Back
3	3	Tools	Options
4	4	Guide	Guide
5	5	CEC	Smart
6	6	?	List
7	7	OK	Ok
8	8	Up	Up
9	9	Down	Down
0	0	Left	Left
FAV	Pre Ch	Right	Right
TXT	Text	Vol +	Vol +
Red	Red	Vol -	Vol -
Green	Green	Source	AV
Yellow	Yellow	Mute	Mute
Blue	Blue	P+	Ch +

Original		Replacement		Original	Replacement
P –	P-	CH –	Ch -		
	Rec	REC MODE	Rec		
	Play	PLAY MODE	Play		
	Pause		Pause		
	Stop		Stop		
	<<		<<		
	>>		>>		
	[. . .]	AD SUBT	Subt		
	[<>]	PICTURE FORMAT	Format		
	Q	DISPLAY INFO	Info		
TV/Radio	Tv/ Radio	SEARCH TV/R	TV/ R		
My Media	My Media	APP MEDIA	Media		
	I <		I <<		
	>I		>>I		