Original		Replacement	
	Power		Power
	Mute		Mute / Dimmer
	Red		Red / Netflix / Search
	Green		Green / APP / Repeat
	Yellow		Yellow / YouTube / Repeat
	Blue		Blue / Prime Video / Random
	Subtitle		Subtitle / EQ
	Text		Text / Goto
	Audio		Audio / Lang I/II
	Recall		Back / Return
	<<		<< / Tune-
	>>		>> / Tune+
	I<<		I<< / Preset-
	>>I		>>I / Preset+
	Play		Play / Slow
	Pause		Pause / Step / Freeze
	Stop		Stop / Hold

Original		Replacement	
	Rec		Rec / Rec Mode
	Menu		Menu / Home
	Up		Up
	Exit		Exit / Cancel / Clear
	Left		Left
	OK		OK
	Right		Right
	EPG		Guide / EPG / -/--
	Down		Down
	i		Info / Angle
	V+		Vol +
	FAV		Fav / Marker / PC
	P+		CH+ / Page+
	V-		Vol -
	Go To		Shift + Text /
	P-		CH- / Page-
1	1		1

Original		Replacement		Original	
2	2	DVD 2	2		
3	3	CD - STB 3	3		
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
OPT	OPT	OPT-TOOLS SETUP	Set up / OPT /		
0	0	HDMI - SAT 0	0		
TV/RADIO	TV/ Radi o	PROGRAM TV/ RADIO	TV/ Radi o /		

Original		Replacement	
POWER		Power	
MUTE		Mute / Dimmer	
RED		Red / Netflix / Search	
GREEN		Green / APP / Repeat	
YELLOW		Yellow / YouTube / Repeat	
BLUE		Blue / Prime Video / Random	
SUB.		Subtitle / EQ	
TXT		Text / Goto	
AUDIO		Audio / Lang I/II	
RECALL		Back / Return	
REW		<< / Tune-	
FWD		>> / Tune+	
PLAY		Play / Slow	
PAUSE		Pause / Step / Freeze	
STOP		Stop / Hold	
REC		Rec / Rec Mode	
MENU		Menu / Home	

Original		Replacement	
UP		Up	
EXIT		Exit / Cancel / Clear	
LEFT		Left	
OK		OK	
RIGHT		Right	
EPG		Guide / EPG / -/--	
DOWN		Down	
i		Info / Angle	
VOL+		Vol +	
FAV		Fav / Marker / PC	
PAGE UP		CH+ / Page+	
VOL-		Vol -	
GO TO		Shift + Text /	
PAGE DOWN		CH- / Page-	
1		1	
2		2	
3		3	

Original		Replacement		Original	
4	4	VIDEO 4	4		
5	5	TAPE 5	5		
6	6	TUNER 6	6		
7	7	AUX - HDD 7	7		
8	8	USB 8	8		
9	9	BLUETOOTH 9	9		
0	0	HDMI - SAT 0	0		
TV/RADIO	TV / RADIO	PROGRAM TV/ RADIO	TV/Radio /		
	---	MEDIA DISPLAY	Display / Media		
	EMAIL	LIST SMART	Smart / List		
	APP	SHIFT + APP REPEAT	Shift + Green / APP /		