Mandis shop

RMT- CS400AD

Original		Replacement	
OPERATE (AC ONLY)	Operate		Power
SLEEP	Sleep	PROG SLEEP	Sleep
FUNCTION	Function	TOP MENU MENU	Menu
1	1	1	1
2	2	2	2
3	3	3	3
4	4	4	4
5	5	5	5
6	6	6	6
7	7	7	7
8	8	8	8
9	9	9	9
0/10	0/10	0	0
>10	>10	-/-- GUIDE	Guide
MODE	Mode	PICTURE FORMAT	Format
VOL +	Vol +	+ VOL	Vol +
	Vol -	VOL –	Vol -

Original		Replacement	
BAND	Band	SEARCH TV/R	TV/R
TUNE +	Tune+	>>	>>
TUNE –	Tune-	<<	<<
▶	Play	PLAY MODE ▶	Play
❚❚	Pause	❚❚	Pause
■	Stop	■	Stop
⏮	I <<	⏮	I <<
⏭	>>I	⏭	>>I
MEGA Xpand	Mega Xpand	SETTINGS OPT	Options
MEGA BASS	Mega Bass	AD SUBT	Subt

https://al-remotecontrols.nl/en/Sony/1628357-replacement-remote-control-for-Sony-RMT-S6D-32886A.htm